THANK YOU FOR PURCHASING A HOTPOINT PRODUCT.

To receive more comprehensive assistance, register the appliance on


www.hotpoint.eu/register

Before using the appliance carefully read the Health and Safety guide.

Before using the machine, it is imperative that the transport bolts are removed. For more detailed instructions on how to remove them, see the Installation Guide.

CONTROL PANEL

- 1. ON/OFF button
- START/PAUSE button
- 3. TEMPERATURE button
- 4. ENERGY SAVER button
- 5. DRY ONLY button / Lock button
- 6. DRYING SETTINGS button
- 7. START DELAY button
- 8. SPIN SPEED button
- 9. WASH CYCLE SELECTOR KNOB



DISPLAY INDICATORS

Washing phase 🗳 🐴 🗐 Indicates washing phase of the cycle

Drying phase 🜣

Energy Saver activated **2**

Key lock activated **─**○

Drying only **½**

Time drying mode 🦄

Drying automatic levels 🗓 🗘 🛆

Start delay activated (4)

Door locked ₼

WASH CYCLE TABLE

Maximum load 7 kg Power input in off mode 0.5 W / in left-on mode 8 W									Detergents and Additives		Recommended detergent		lal ss %	Energy consumption kWh	ter It	lry ure °C
	Wash cycle	Temperature		Maximum spin		Max. load for drying	Duration	Drying	Wash	Fabric softener	Powder	Liauid	Residual dampness (***)	Energ Isump KWh	Total water It	Laundry temperature °
	rrasii eyele	Setting	Range		cycle (kg)	cycle (kg)	(h:m)	D.	2	3		Liquid	daı	cor	Tot	l tem
1	Mixed Wash&Dry	40 °C	40 °C	800	3,5	3,5	**			0	_	~	_	_	_	_
2	Shirts and T-shirts	40 °C	40 °C	1000	2,0	2,0	**			0	-	~	_	_	_	_
3	Pre Iron	-	_	_	1,0	-	**	-	_	_	-	_	_	_	_	_
4	Steam Refresh	-	-	-	1,0	-	**	-	_	-	-	_	_	_	_	_
5	Cotton (2)	40 °C	₩ -60°C	1400	7,0	5,0	3:40			0	~	~	50	1,0	75	45
6	Synthetics (3)	40 °C	₩ -60°C	1200	4,0	4,0	2:55			0	~	~	35	0,9	60	43
7	Anti Stain Quick	40 °C	※ -40℃	1200	3,5	3,5	**			0	-	~	-	-	_	_
8	Anti Stain 40°	40 °C	※ -40°C	1400	7,0	5,0	**			0	_	~	_	_	_	_
9	White	60 °C	※ -90℃	1400	7,0	5,0	2:30			0	~	~	52,1	1,4	75	55
	Eco 40-60 (1) (Wash)	40°C	40°C	1351	7,0	5,0	3:25			0	~	~	53	0,89	47	35
10				1351	3,5	2,5	2:40			0	~	~	53	0,57	45	34
				1351	2	_	2:10			0	~	~	53	0,52	39	33
11	20°C	20 °C	※ -20℃	1400	7,0	5,0	1:50			0	-	~	52	0,2	64	22
12	Delicates	30 °C	※ -30°C	600 (****)	1,0	1,0	**			0	-	~	_	_	_	-
13	Wool	40 °C	※ -40℃	800	1,5	1,5	**			0	_	~	_	_	_	_
14	Rapid 30'	30 °C	※ -30°C	1200(****)	3,5	-	0:30	_		0	_	~	73	0,2	31	27
4174 ©	Rinse & Spin	_	-	1400	7,0	5,0	_	•	-	0	-	-	_	-	-	_
P.	Spin & Drain *	-	-	1400	7,0	5,0	_	•	-	-	-	-	-		-	_
● Required dosage O Optional dosage																
10	Eco 40-60 (4)	40 °C	40°C	1351	5,0	5,0	9:20			0	~	~	0	3,80	75	36
	(Wash&Drying)	40 C		1351	2,5	2,5	5:00			0	~	~	0	2,40	52	36

For wash programmes with temperatures above 50°C, we recommend using powder detergent rather than liquid, and following the directions given on the detergent package.

This data may differ in your home due to changing conditions in inlet water temperature, water pressure etc. Approximate programme duration values refer to the default setting of the programmes, without options. The values given for programmes other than the Eco 40-60 programme are indicative only.

For all Test Institutes

1) Eco 40-60 (Wash) - Test wash cycle in compliance with EU Ecodesign regulation 2019/2014. The most efficient programme in terms of energy and water consumption for washing normally soiled cotton


4) Eco 40-60 (Wash&Drying)- Test wash&drying cycle in compliance with EU Ecodesign regulation 2019/2014. To access "wash and dry" cycle select "Eco 40-60" wash programme and set "Drying" option level to "[...]". The most efficient programme in terms of energy and water consumption for washing and drying normally soiled cotton laundry. At the end of cycle the garments can be immediately stored to the cupboard.

For all testing institutes:

- 2) Long cotton cycle: set programme 5 at temperature 40°C.
- 3) Long synthetics cycle: set cycle 6 at a temperature of 40°C.
- * By selecting the cycle and excluding the spin cycle, the washer-dryer will drain only.
- ** The duration of the programme is shown on the display.
- *** After programme end and spinning with maximum selectable spin speed, in default
- **** The display will show the suggested spin speed as default value.

PRODUCT DESCRIPTION

- 1. Worktop
- 2. Detergent dispenser
- 3. Control panel
- 4. Door handle
- 5. Door
- 6. Water filter
- 7. Adjustable feet (4)



DETERGENT DISPENSER

Compartment 1:

Do not insert detergent in this compartment.

Compartment 2: Washing detergent (powder or liquid)

Compartment 3: Additives (fabric softeners, etc.)

The fabric softener must not exceed the "MAX"

! Use powder detergent for white cotton garments, for pre-washing, and for washing at temperatures over 60°C.

! Follow the instructions given on the detergent packaging.



WASH CYCLES

Follow the instructions on the symbols of the garment's wash care label. The value indicated in the symbol is the maximum recommended temperature for washing the garment.



Mixed Wash&Dry

use programme 1 to wash and dry mixed garments (cotton and synthetics). This cycle may be used to wash and dry loads of up to 3,5 kg; we recommend the use of liquid detergent.

The use of the steam in this programme is optimised to reduce the formation of creases on garments, making them easier to iron.

Shirts and T-shirts

Use programme 2 to wash and dry shirts and T-shirts in different fabrics and colours to ensure maximum care. This cycle may be used to wash and dry loads of up to 2 kg. To achieve optimum results, use liquid detergent and pre-treat cuffs, collars and stains. The use of the steam in this programme is optimised to reduce the formation of creases on garments, making them easier to iron.

Pre Iron

Use this programme immediately before ironing; max. 1 kg load. The use of the steam in this programme is optimised to reduce the formation of creases on garments, making them easier to iron.

Steam Refresh

For refreshing garments, neutralised unpleasant odours and relaxing the fibres by delivering steam into the drum. The garments will be damp at the end of the cycle.

Cotton

Suitable for washing towels, underwear, table cloths, etc. made of resistant linen and cotton that are moderately to heavily soiled.

Synthetics

Suitable for washing moderately soiled garments made of synthetic fibres (e.g. polyester, polyacrylic, viscose, etc.) or mixed synthetic-cotton

Anti Stain Quick

this programme is ideal for washing the most difficult daily stains in 45'. It is ideal for mixed fabrics and coloured garments, caring for your clothes as it washes.

If the drying function is selected, a drying cycle automatically activates at the end of the wash cycle that resembles open-air drying, with the added advantages of preserving garments from yellowing due to sunlight exposure and preventing loss of whiteness caused by the possible presence of dust in the air. Dryness level "△" recommended.

Anti Stain 40°

the programme is suitable to heavily-soiled garments with resistant colours. It ensures a washing class that is higher than the standard class (A class). When running the programme, do not mix garments of different colours. We recommend the use of powder detergent. Pre-treatment with special additives is recommended if there are obstinate stains. If the drying function is selected, a drying cycle automatically activates at

the end of the wash cycle that resembles open-air drying, with the added advantages of preserving garments from yellowing due to sunlight exposure and preventing loss of whiteness caused by the possible presence of dust in the air. Dryness level "△" recommended.

White

For heavily soiled whites and resistant colours.

Eco 40-60

For washing normally soiled cotton garments declared to be washable at 40 $^{\circ}\text{C}$ or 60 °C, together in the same cycle. This is the standard cotton programme and the most efficient in terms of water and energy consumption.

20°C

For washing lightly soiled cotton garments, at a temperature of 20 °C.

For washing very delicate garments. It is advisable to turn the garments inside out beforé washing them. For best results, use liquid detergent on delicate garments.

We recommend turning the garments inside out before washing and placing small items into the special bag for washing delicates. Use liquid detergent on delicate garments for best results.

When selecting an exclusively time-based drying function, a drying cycle is performed at the end of the wash cycle that is particularly delicate, thanks to light handling and appropriate temperature control of the water jet. The recommended durations are:

1 kg of synthetic garments --> 150 min

1 kg of synthetic and cotton garments --> 180 min

1 kg of cotton garments --> 180 min

The degree of dryness depends on the load and fabric composition.

All wool garments can be washed using programme, "Wool" even those carryng the "hand-wash only " label. For best results, use special detergents and do not exceed max kg declaration of laundry. Rapid 30'

For washing lightly soiled garments in a short time. Not suitable for wool, silk and garments to be washed by hand.

Rinse & Spin

Designed for rinsing and spinning.

Spin & Drain

Designed for spinning and draining the water.

☑ Door locked indicator

if the 🖾 symbol is off the door is locked. To prevent any damage, wait until the symbol turns on before opening the door.

To open the door while a cycle is in progress, press the START/PAUSE button ▷ (if the symbol is lit, the door can be opened.

FIRST-TIME USE

Once the appliance has been installed, and before it is used for the first time, run a wash cycle with detergent and no laundry, by setting the cycle 9(60°C).

DAILY USE

Prepare the laundry by following the suggestions appearing under the "TIPS AND SUGGESTIONS" section.

- Press the ON/OFF button (¹); the indicator light relative to START/PAUSE \(\) will flash slowly.
- Open the door. Load the laundry while making sure not to exceed the maximum load quantity indicated in the wash cycle table.
- Pull out the detergent dispenser drawer and pour the detergent into the relevant compartments, as described in the "DETERGENT DISPENSER DRAWER" section.
- Close the door.
- The machine automatically displays the default temperature and spin speed values for the selected cycle, or the most recently used settings if they are compatible with the selected cycle.
- Select the desired wash cycle.
- Select the desired options.

STARTING CYCLE

Press the START/PAUSE ▷∭ button.

The machine will lock the door (symbol on) and the drum will start to rotate; the door will be unlocked (ৰ্প্ৰ symbol OFF) and then locked again (on) as preparation phase of each washing cycle. The "Clicking" noise is part of the door locking mechanism. Water will enter the drum and start the washing phase once the door is locked.

PAUSING A CYCLE

To pause the wash cycle, press the START/PAUSE [>∏] button again; the indicator light will flash. If the ☑ symbol is lit, the door may be opened. To start the wash cycle from the point at which it was interrupted, press the START/PAUSE Dill button again.

OPENING THE DOOR, IF NECESSARY

Once a cycle starts, the 🖾 symbol turns off to signal that the door cannot be opened. While a wash cycle is running, the door remains locked. To open the door while a cycle is under way, for example, to add or remove garments, press the START/PAUSE ▷∭ button to pause the cycle; the indicator light will flash. If the 🖾 symbol is lit, the door may be opened. Press the START/PAUSE \ D wtton again to continue the cycle.

CHANGING A RUNNING WASH CYCLE

To change a wash cycle while it is in progress, pause the washer-dryer using select the desired cycle and press the START/PAUSE $\triangleright M$ button again. ! To cancel a cycle that has already begun, press and hold the ON/OFF (1) button. The cycle will be stopped and the machine will switch off.

AT THE END OF THE WASH CYCLE

This will be indicated by the word "END" on the display; when the @ symbol switches on, the door may be opened. Open the door, unload the laundry and switch off the machine. If you do not press "ON/OFF" button, the washer-dryer will switch off automatically after about a 10 minutes. Close the water tap, open the door and unload the washer-dryer. Leave the door ajar to allow the drum to dry.

OPTIONS

! If the selected option is incompatible with the programme set, the incompatibility will be signalled by a buzzer and the corresponding indicator light will flash.

! If the selected option is incompatible with another previously set option, only the most recent selection will remain active.

Energy saver

This option saves energy by not heating the water used to wash your laundry – an advantage both to the environment and to your energy bill. Instead, intensified wash action and water optimisation ensure great wash results in the same average time of a standard cycle. For the best washing results we recommend the usage of a liquid detergent.

Start Delay

To set the selected programme to start at a later time, press the button to set the desired delay time. The \mathcal{C}_h symbol lights on the display when this function is enabled. To cancel the delayed start, press the button again until the value "0" is shown on the display.

Each wash cycle has a pre-defined temperature. To modify the temperature, press the "Temp." button. The value will appear on the display.

Spin

Each wash cycle has a pre-defined spin speed. To modify the spin speed, press the **"Spin Speed"** button. The value will appear on the display.

Setting the drying cycle

The first time the button "**Drying Settings**" is pressed, the machine will automatically select the maximum drying cycle which is compatible with the selected wash cycle. Subsequent presses will decrease the drying level and then the drying time, until the cycle is excluded completely ("OFF"). Drying may be set as follows:

A-Based on the desired laundry dryness level:

Cupboard : suitable for laundry which can be put back in a cupboard

without being ironed.

Hanger ≤ : ideal for clothes which do not need to be dried fully.

Iron ⊇: suitable for clothes which will need ironing afterwards. the remaining dampness softens creases, making them easier to remove.

B - Based on a set time period: between 210 and 30 minutes.

If your laundry load to be washed and dried is much greater than the maximum stated load (see adjacent table of wash cycles), perform the wash cycle, and when the cycle is complete, divide the garments into groups and put some of them back in the drum. At this point, follow the instructions provided for a "Drying only" cycle. Repeat this procedure for the remainder of the load. Note: a cooling-down period is always added to the end of each drying cycle.

Drying only

Press button "Dry only" to perform the drying-only cycle. After selecting the desired cycle (compatible with the type of garments), press button "Dry only" to exclude the washing phase and start the drying phase at the maximum level for the selected cycle. The drying level or time may be set and changed by pressing the drying button "Drying Settings".

KEY LOCK ─○

to lock the control panel, press and hold the button "**Dry only**" for approximately 3 seconds. the symbol —O lights on the display to indicate that the control panel is locked (with the exception of the () button). This prevents unintentional changes to programmes, especially with children near the machine.

If any attempt is made to use the control panel, the symbol =—O flashes on the display.

To unlock the control panel, press and hold the button "Dry only" for approximately 3 seconds.

TIPS AND SUGGESTIONS

Divide the laundry according to:

Type of fabric (cotton, mixed fibres, synthetics, wool, garments to be hand-washed). Colour (separate coloured garments from whites, wash new coloured garments separately). Delicates (small garments – such as nylon stockings – and items with hooks – such as bras: insert them in a fabric bag).

Empty the pockets:

Objects such as coins or lighters can damage the washer-dryer and the drum. Check all buttons.

Follow the dosage recommendation / additives

It optimizes the $c\bar{l}$ eaning result, it avoids irritating residues of surplus detergent in your laundry and it saves money by avoiding waste of surplus detergent

Use low temperature and longer duration

The most efficient programmes in terms of energy consumption are generally those that perform at lower temperatures and longer duration.

Observe the load sizes

Load your washer-dryer up to the capacity indicated in the "PROGRAMME CHART" table to save water and energy.

Noise and remaining moisture content

They are influenced by the spinning speed: the higher the spinning speed in the spinning phase, the higher the noise and the lower the remaining moisture content.

CARE AND MAINTENANCE

Before performing cleaning and maintenance, switch the washer-dryer off and disconnect it from the mains power. Do not use flammable liquids to clean the washer-dryer. Clean and maintain your washer - dryer periodically (at least 4 times per year).

Disconnect the water and power supplies

Close the water tap after every wash. This will limit wear on the hydraulic system inside the and help to prevent leaks.

Unplug the washer-dryer when cleaning it and during all maintenance work.

Clean the washer-dryer

The outer parts and rubber components of the appliance can be cleaned using a soft cloth soaked in lukewarm soapy water. Do not use solvents or abrasives.

Clean the detergent dispenser drawer

Wash it under running water; this operation should be repeated frequently.

Care for the door and drum

Always leave the porthole door ajar in order to prevent unpleasant odours from forming.

Clean the pump

The washer-dryer is fitted with a auto-cleaning pump that does not require any maintenance. Small items (such as coins or buttons) may sometimes fall into the protective pre-chamber situated at the base of the pump.

! Make sure the wash cycle has ended and unplug the appliance. To access the pre-chamber:

- 1. loosen the drainage pump cover by turning it anti-clockwise: it is normal for some water to leak out;
- 2. clean the inside thoroughly;
- 3. screw the cover back on;

Check the water inlet hose

Check the water inlet hose at least once a year. If it is cracked or broken, it must be replaced: during wash cycles, the high pressure of the water could suddenly split the hose open.

! Never use hoses that have already been used.

LOAD BALANCING SYSTEM

Before every spin cycle, to avoid excessive vibrations before every spin and to distribute the load in a uniform manner, the drum rotates continuously at a speed which is slightly greater than the washing rotation speed. If, after several attempts, the load is not balanced correctly, the machine spins at a reduced spin speed. If the load is excessively unbalanced, the washerdryer performs the distribution process instead of spinning. To encourage improved load distribution and balance, we recommend small and large garments are mixed in the load.

TRANSPORT AND HANDLING

Do not lift the washer-dryer by gripping it from the upper section. Unplug the appliance and close the water tap. Check that the door and detergent dispenser drawer are tightly closed. Detach the filling hose from the water tap then detach the drain hose. Empty all the water remaining in the hoses and secure the latter so that they do not get damaged during transport. Apply the transport bolts back on. Repeat, in reverse order, the transport bolt removal procedure described in the "Health & Safety and Installation Guides".

TRANSPORT AND HANDLING

Do not lift the washer-dryer by gripping it from the upper section. Unplug the appliance and close the water tap. Check that the door and detergent dispenser drawer are tightly closed. Detach the filling hose from the water tap then detach the drain hose. Empty all the water remaining in the hoses and secure the latter so that they do not get damaged during transport. Apply the transport bolts back on. Repeat, in reverse order, the transport bolt removal procedure described in the "Installation instructions".

TROUBLESHOOTING

Your washer-dryer could occasionally fail to work. Before contacting the Technical Assistance Service, make sure that the problem cannot be easily solved using the following list.

Anomalies	Possible causes / Solution							
The washer-dryer does not	The appliance is not plugged into the socket fully, or not enough to make contact.							
start.	There is no power in the house.							
	The washer-dryer door is not closed properly.							
	The ON/OFF (1) button has not been pressed.							
The wash cycle does not start.	The START/PAUSE ▷ button has not been pressed.							
	The water tap has not been opened.							
	A delay has been set for the start time.							
	The water inlet hose is not connected to the tap.							
	The hose is bent.							
The washer-dryer does not fill with water ("H2O" appears on	The water tap has not been opened.							
the display).	There is no water supply in the house.							
	The pressure is too low.							
	The START/PAUSE ▷∭ button has not been pressed.							
	The drain hose is not fitted between 65 and 100 cm from the floor.							
	The free end of the hose is immersed in water.							
The washer-dryer	The wall drainage system is not fitted with a breather pipe.							
continuously loads and unloads water.	If the problem persists even after these checks, turn off the water tap, switch the appliance off and contact the Technical Assistance Service. If the home is on one of the upper floors of a building, there may be problems relating to back-siphonage, causing the washer-dryer to fill with water and drain continuously. Special anti-siphon valves are available in shops and help to prevent this inconvenience.							
	The cycle does not include drainage: with certain cycles it must be started manually.							
The washer-dryer does not drain or spin.	The drain hose is bent.							
шшш от орин	The drainage duct is clogged.							
	The drum was not unlocked correctly during installation.							
The washer-dryer vibrates a lot during the spin cycle.	The washer-dryer is not level.							
iot augop cycle.	The washer-dryer is tucked between furniture cabinets and the wall.							
	The water inlet hose is not screwed on properly.							
The washer-dryer leaks.	The detergent dispenser drawer is obstructed.							
	The drain hose is not properly attached.							
The START/PAUSE [>10] indicator light flash rapidly and an error code appears on the display (e.g.: F-01, F).	Switch off the machine and unplug it, wait for approximately 1 minute and then switch it back on again. If the problem persists, contact the Technical Assistance Service.							
There is too much foam.	The detergent is not suitable for machine washing (it should display the text "for washer-dryers" or "hand and machine wash", or the like).							
	Too much detergent was used.							
	The appliance is not plugged into the socket, or not enough to make contact.							
	There has been a power failure.							
The washer-dryer does not dry.	The appliance door is not shut properly.							
ы у.	A Delay has been set.							
	DRYING is in the OFF position.							
The machine can be heard taking in water during the drying cycle.	in water during the lit is normal for the machine to take in short bursts of water during the drying cycle. This helps keep some international and aids speed of drying							

DEMO MODE: to deactivate this function, switch the washer-dryer OFF. Than press and hold "Start/Pause" [30] button, within 5 seconds press also "ON/OFF" (1) button and hold both buttons for 2 seconds.



- You can download the H&S INSTRUCTIONS, PRODUCT FICHE and ENERGY DATA by:

 Visiting our website http://docs.hotpoint.eu.

 Using QR code

 Alternatively, contact our After-sales Service (See phone number in the warranty booklet). When contacting our After-sales Service, please state the codes provided on your product's identification plate.

 For User's Repair & Maintenance Information visit www.hotpoint.eu

You can find more information about your model online at https://eprel.ec.europa.eu/ which is the official EU EPREL product database. After selecting the Product Category, enter the Model Identifier of the product. The Model Identifier is made up of letters and numbers and can be found on the identification plate, as Mod. (see image on the right).



CLEANING & MAINTENANCE

For any cleaning and maintenance, switch off and unplug the washing machine. Do not use flammable fluids to clean the washing machine.


CLEANING THE OUTSIDE OF THE WASHING MACHINE

Use a soft damp cloth to clean the outer parts of the washing machine.


Do not use glass or general purpose cleaners, scouring powder or similar to clean the control panel – these substances might damage the printing.

CHECKING THE WATER SUPPLY HOSE

Check the inlet hose regularly for brittleness and cracks. If damaged, replace it by a new hose available through our After-Sales Service or your specialist dealer. Depending on the hose type:




If the inlet hose has a transparent coating, periodically check if the colour intensifies locally. If yes, the hose may have a leak and should be replaced.



For water stop hoses: check the small safety valve inspection window (see arrow). If it is red, the water stop function was triggered, and the hose must be replaced by a new one. For unscrewing this hose, press the release button (if available) while unscrewing the hose.

CLEANING THE MESH FILTERS IN THE WATER SUPPLY HOSE


1. Close water tap and unscrew the inlet hose.




2. Clean the mesh filter at the hose's end carefully with a fine brush.



3. Now unscrew the inlet hose on the back of the washing machine by hand. Pull out the mesh filter from the valve on the back of the washing machine with pliers and carefully clean it.




4. Insert the mesh filter again. Connect the inlet hose to water tap and washing machine again. Do not use a tool to connect the inlet hose. Open the water tap and check that all connections are tight.



CLEANING THE DETERGENT DISPENSER

Remove the dispenser by raising it and pulling it out (see figure).

Wash it under running water; this operation should be repeated frequently.



CLEANING THE WATER FILTER / DRAINING RESIDUAL WATER

Switch off and unplug the washing machine before cleaning the water filter or draining residual water. If you used a hot wash programme, wait until the water has cooled down before draining any water.

Clean the water filter regularly every 3 months, to avoid that the water cannot drain after the wash due to obstruction of the filter. If the water cannot drain, the display indicates that the water filter may be clogged.

1. Remove plinth.




2. Container for the drained water:
Place a low and wide container under the water filter in
order to collect the residual water.



3. Drain the water:
Slowly turn the filter counter-clockwise until all the water has come out. Allow the water to flow out without removing the filter. Once the container is full, close the water filter by turning it clockwise. Empty the container. Repeat the procedure until all the water has been drained.



4. Remove filter: Lay a cotton cloth beneath the water filter, which can absorb a small amount of rest water. Then remove the water filter by turning it out anticlockwise.



Clean the water filter: remove residues in the filter and clean it under running water.



6. Insert the water filter and reinstall the plinth: Reinsert the water filter again by turning it in clockwise direction. Make sure to turn it in as far as it goes; the filter handle must be in vertical position. To test water tightness of the water filter, you can pour about 1 liter of water into the detergent dispenser. Then reinstall the plinth.



TRANSPORT AND HANDLING

Never lift the washing machine by holding it at the worktop.

- 1. Pull out the mains plug, and close the water tap.
- Make sure that door and detergent dispenser are properly closed.
- **3.** Disconnect the inlet hose from the water tap, and remove the drain hose from your draining point. Remove all rest water from the hoses, and fix them so that they cannot get damaged during transport.
- **4.** Refit the transport bolts. Follow the instructions for removing the transport bolts in the "Installation Guide" in reverse order.

Important: Do not transport the washing machine without having fixed the transport bolts.

AFTER-SALES SERVICE

BEFORE CALLING THE AFTER-SALES SERVICE


- 1. See if you can solve the problem by yourself with the help of the suggestions given in the **TROUBLESHOOTING**
- 2. Switch the appliance off and back on again to see if the fault persists.

IF AFTER THE ABOVE CHECKS THE FAULT STILL OCCURS, GET IN TOUCH WITH THE NEAREST AFTER-SALES SERVICE

To receive assistance, call the number shown on the warranty booklet.

When contacting our Client After sales service, always specify:

- a brief description of the fault;
- the type and exact model of the appliance;



the service number (number after the word Service on the rating plate).



- your full address;
- your telephone number.

If any repairs are required, please contact an authorised aftersales service (to guarantee that original spare parts will be used and repairs carried out correctly).