





**THANK YOU FOR BUYING A HOTPOINT PRODUCT**  
In order to receive a more complete assistance, please register your product on [www.register10.eu](http://www.register10.eu)

**PLEASE SCAN THE QR CODE ON YOUR APPLIANCE IN ORDER TO REACH MORE INFORMATION**




Before using the appliance carefully read the Safety Instruction.

## PRODUCT DESCRIPTION



1. Control panel
2. Fan and circular heating element (non-visible)
3. Shelf guides (the level is indicated on the front of the oven)
4. Door
5. Upper heating element/grill
6. Lamp
7. Identification plate (do not remove)
8. Lower heating element (non-visible)

## CONTROL PANEL



### 1. ON / OFF

For switching the oven on and off and for stopping an active function.

### 2. FUNCTIONS DIRECT ACCESS

For quick access to the functions and menu.

### 3. NAVIGATION BUTTON MINUS

For scrolling through a menu and decreasing the settings or values of a function.

### 4. BACK

For returning to the previous screen. During cooking, allows settings to be changed.

### 5. DISPLAY

### 6. CONFIRM

For confirming a selected function or a set value.

### 7. NAVIGATION BUTTON PLUS

For scrolling through a menu and increasing the settings or values of a function.

### 8. OPTIONS / FUNCTIONS DIRECT ACCESS


For quick access to the functions, duration, settings and favorites.

### 9. START

For starting a function using the specified or basic settings.


# ACCESSORIES

## WIRE SHELF




Use to cook food or as a support for pans, cake tins and other ovenproof items of cookware.

## DRIP TRAY




Use as an oven tray for cooking meat, fish, vegetables, focaccia, etc. or position underneath the wire shelf to collect cooking juices.

## BAKING TRAY\*




Use for cooking all bread and pastry products, but also for roasts, fish en papillote, etc.

## SLIDING RUNNERS\*




To facilitate inserting or removing accessories.

## TURNSPIT




## MEAT PROBE \*




To accurately measure the core temperature of food during cooking.

## AIR FRY TRAY \*



To be used when cooking foods with Air Fry function, with a baking tray positioned at a lower level to collect possible crumbs and drip. It can be cleaned in the dishwasher.

## GRILL PAN SET \*



To be used for grilling meat, fish, vegetables, etc. Place the grid inside the drip tray filled with 500 ml of water to prevent smoking. Position the Grill Pan Set at the level suggested for the wire shelf. Since the drip tray is already used, no additional tray is needed on lower levels.

The number and the type of accessories may vary depending on which model is purchased.

Other accessories can be purchased separately; for orders and information contact the after sales service.

\* Available only in certain models

## INSERTING THE WIRE SHELF AND OTHER ACCESSORIES

Insert the wire shelf horizontally by sliding it across the shelf guides, making sure that the side with the raised edge is facing upwards.


Other accessories, such as the drip tray and the baking tray, are inserted horizontally in the same way as the wire shelf.

## REMOVING AND REFITTING THE SHELF GUIDES

- To remove the shelf guides, lift them up and pull the lower parts out of their lodgings: The shelf guides can now be removed.
- To refit the shelf guides, first fit them back into their upper seating. Keeping them held up, slide them into the cooking compartment, then lower them into position in the lower seating.


## FITTING THE SLIDING RUNNERS

Remove the shelf guides from the oven and remove the protective plastic from the sliding runners. Fasten the upper clip of the runner to the shelf guide and slide it along as far as it will go. Lower the other clip into position. To secure the guide, press the lower portion of the clip firmly against the shelf guide. Make sure that the runners can move freely. Repeat these steps on the other shelf guide on the same level.



Please note: The sliding runners can be fitted on any level.


## USING THE TURNSPIT



Push the skewer through the centre of the meat (bound with string if poultry) and slide the meat onto the skewer until it is positioned firmly on the fork and cannot move. Push the second fork onto the skewer and slide it on until it holds the meat firmly in place. Tighten the fixing screw to secure it in position.

Insert the end into the recess provided in the oven's cooking compartment and rest the rounded part on the relevant support.

Please note: To collect the cooking juices, position the drip tray below and add 500 ml of water. To avoid burning yourself when the skewer is hot, only handle it by the plastic handle (which must be removed before cooking).



# FUNCTIONS



## CONVENTIONAL

For cooking any kind of dish on one shelf only.



## FORCED AIR

For cooking different foods that require the same cooking temperature on several shelves (maximum three) at the same time. This function can be used to cook different foods without odours being transferred from one food to another.



## GRILL

For grilling steaks, kebabs and sausages, cooking vegetables au gratin or toasting bread. When grilling meat, we recommend using a drip tray to collect the cooking juices: Position the tray on any of the levels below the wire shelf and add 500 ml of drinking water.



## MY MENU

These allow a fully automatic cooking for all types of food (Lasagna, Meat, Fish, Vegetables, Cakes & Pastries, Salt cakes, Bread, Pizza). To get the best from this function, follow the indications on the relative cooking table.

## MANUAL FUNCTIONS

### • CONVECT BAKE

For cooking meat, baking cakes with fillings on one shelf only

### • MULTIFLOW MENU

For cooking different foods that require the same cooking temperature on four levels at the same time. This function can be used to cook cookies, cakes, round pizzas (also frozen) and to prepare a complete meal. Follow the cooking table to obtain the best results.

### • TURBO GRILL

For roasting large joints of meat (legs, roast beef, chicken). We recommend using a drip tray to collect the cooking juices: Position the pan on any of the levels below the wire shelf and add 500 ml of drinking water.

### • FROZEN BAKE

The function automatically selects the ideal cooking temperature and mode for 5 different types of ready frozen food. The oven does not have to be preheated.

### • SPECIAL FUNCTIONS

#### » PIZZA

This function allows you to cook great homemade pizza, in less than 10 minutes like in a restaurant. "This function allows you to cook great homemade pizza, in less than 10 minutes like in a restaurant.

The dedicated cooking cycle works at temperature level above 300 degree Celsius, delivering pizza soft inside, crunchy on the

edges and with a perfectly even browning. Combining this function with the Pizza Stone WPro accessory and preheating for 30 minutes can bake a pizza in 5-8 min. (For orders and information contact the after sales service or [www.hotpoint.eu](http://www.hotpoint.eu).)"

#### » RISING

For optimal proving of sweet or savoury dough. To maintain the quality of proving, do not activate the function if the oven is still hot following a cooking cycle.

#### » KEEP WARM

For keeping just-cooked food hot and crisp.

#### » DEFROST

To speed up defrosting of food. Place food on the middle shelf. Leave food in its packaging to prevent it from drying out on the outside.

#### » ECO CYCLE \*

For cooking stuffed roasting joints and fillets of meat on a single shelf. When this Eco Cycle is in use, the light will remain switched off during cooking. To use the Eco Cycle and therefore optimise power consumption, the oven door should not be opened until the food is completely cooked.

#### » MAXI COOKING

The function automatically selects the best cooking mode and temperature to cook large joints of meat (above 2.5 kg). It is advisable to turn the meat over during cooking, to obtain even browning on both sides. It is best to baste the meat every now and again to prevent it from drying out.

#### » SLOW COOKING

To gently cook meat and fish. This function cooks food slowly to keep it tender and succulent. Due to the low temperature, the food does not brown on the outside and the end result is similar to steam cooking. We recommend searing roast meat in a pan first to brown the meat and help seal in its natural juices. For best results, keep the oven door closed during cooking in order to avoid heat dispersion. Suggested cooking times ranges for fish (300 g - 3 kg) are between 2-5 hours, for meat (1-3 kg) between 4-7 hours.



## AIR FRY

This function allows you to cook French fries, chicken nuggets and more using less oil, resulting pleasantly crispy. Heating elements cycle to properly heat the cavity, while the fan circulates hot air. Best expected cooking results can be achieved only by using an Air Fry tray (provided with some models). Position the food on the Air Fry tray in a single layer and follow Air Fry Cooking Table instructions for best performances.

---

Avoid using more than one tray to prevent uneven cooking.

 **FAST PREHEAT**

For preheating the oven quickly.

 **MINUTE-MINDER**

For keeping time without activating a function.

 **CLEANING**

- **PYRO**

For eliminating cooking spatters using a cycle at very high temperature. Two selfcleaning cycles are available: A complete cycle (Pyro) and a shorter cycle (Pyro Eco). We recommend using the quicker cycle at regular intervals and the complete cycle only when the oven is heavily soiled.

- **DIAMOND CLEAN**

The action of the steam released during this special low-temperature cleaning cycle allows dirt and food residues to be removed with ease. Pour 200 ml of drinking water on the bottom of the oven and only activate the function when the oven is cold.

 **FAVORITES**

For retrieving the list of 10 favorite functions.

 **SETTINGS**

For adjusting the oven settings. When "ECO" mode is active the brightness of the display will be reduced to save energy and lamp switches off after 1 minute. It will be reactivated automatically whenever any of the buttons are pressed. When "DEMO" is "On" all commands are active and menus available but the oven doesn't heat up. To deactivate this mode, access "DEMO" from "SETTINGS" menu and select "Off". By selecting "FACTORY RESET", the product switches off and then it returns to first switch on. All settings will be deleted.

\* Function used as reference for the energy efficiency declaration in accordance with Regulation (EU) No. 65/2014.

---

# FIRST TIME USE


---

## 1. SELECT THE LANGUAGE

You will need to set the language and the time when you switch on the appliance for the first time: "English" will show on the display.



Press **+** or **-** to scroll through the list of available languages and select the one you require. Press  to confirm your selection.


Please note: The language can subsequently be changed by selecting "LANGUAGE" in "SETTINGS" menu, available by pressing .

## 2. SET THE TIME

After selecting the language, you will need to set the current time: The two digits for the hour will flash on the display.



Press **+** or **-** to set the correct hour and press  : The two digits for the minutes will flash on the display. Press **+** or **-** to set the minutes and press  to confirm.

Please note: You may need to set the time again following lengthy power outages. Select "CLOCK" in "SETTINGS" menu, available by pressing .

## 3. HEAT THE OVEN


A new oven may release odours that have been left behind during manufacturing: This is completely normal.


Before starting to cook food, we therefore recommend heating the oven with it empty in order to remove any possible odours. Remove any protective cardboard or transparent film from the oven and remove any accessories from inside it. Heat the oven to 200 °C for around one hour, ideally using a function with air circulation (e.g. "Forced Air" or "Convection Bake").

Please note: It is advisable to air the room after using the appliance for the first time.

# DAILY USE

## 1. SELECT A FUNCTION


Press  to switch on the oven: the display will show the last running main function or the main menu.


The functions can be selected by pressing the icon for one of the main functions or by scrolling through a menu: To select an item from a menu (the display will show the first available item), press  $+$  or  $-$  to select the desired one, then press  to confirm.

## 2. SET THE FUNCTION

After having selected the function you require, you can change its settings. The display will show the settings that can be changed in sequence. Pressing  $\ll$  allows you to change the previous setting again

### TEMPERATURE / GRILL LEVEL








When the value flashes on the display, press  $+$  or  $-$  to change it, then press  to confirm and continue with the settings that follow (if possible).



In the same way, it is possible to set the grill level: There are three defined power levels for grilling: 3 (high), 2 (mid), 1 (low).

Please note: Once the function has been activated, the temperature/grill level can be changed using  $+$  or  $-$ , after pressing the  $^{\circ}\text{C}$  button.


### DURATION




When the  icon flashes on the display, press  $+$  or  $-$  to set the cooking time you require and then press  to confirm. You do not have to set the cooking time if you want to manage cooking manually (untimed): Press  or  to confirm and start the function. By selecting this mode, you cannot program a delayed start.

Please note: You can adjust the cooking time that has been set during cooking by pressing : press  $+$  or  $-$  to amend it and then press  to confirm.


### END TIME (START DELAY)

In many functions, once you have set a cooking time you can delay starting the function by programming its end time. The display shows the end time while the  icon flashes.



Press  $+$  or  $-$  to set the time you want cooking to end, then press  to confirm and activate the function. Place the food in the oven and close the

door: The function will start automatically after the period of time that has been calculated in order for cooking to finish at the time you have set.

Please note: Programming a delayed cooking start time will disable the oven preheating phase: The oven will reach the temperature you require gradually, meaning that cooking times will be slightly longer than those listed in the cooking table. During the waiting time, you can press  $+$  or  $-$  to amend the programmed end time or press  $\ll$  to change other settings. By pressing , in order to visualize information, it is possible to switch between end time and duration.


## 3. MY MENU

These functions automatically select the best cooking mode, temperature and duration to cook, roast or bake all the dishes available.

When required, simply indicate the characteristic of food to obtain an optimal result.

### WEIGHT / HEIGHT (ROUND-TRAY-LAYERS)





To set the function correctly, follow the indications on the display, when prompted, and press  $+$  or  $-$  to set the required value then press  to confirm.

### DONENESS / BROWNING


In some MY MENU functions it is possible to adjust the doneness level.





When prompted, press  $+$  or  $-$  to select the desired level between rare (-1) and well done (+1). Press  or  to confirm and start the function.

In the same way, where allowed, in some MY MENU functions, it's possible to adjust the browning level between low (-1) and high (+1).

## 4. START THE FUNCTION

At any time, if the default values are those desired or once you have applied the settings you require, press  to activate the function.


During the delay phase, by pressing  the oven will ask if you want to skip this phase, starting immediately the function.

Please note: Once a function has been selected, the display will recommend the most suitable level for each function. At any time you can stop the function that has been activated by pressing .

If the oven is hot and the function requires a specific maximum temperature, a message will shown on the display. You can either select a different function or wait for a complete cooling.

## 5. PREHEATING

Some functions have an oven preheating phase: Once the function has started, the display indicates that the preheating phase has been activated.



Once this phase has finished, an audible signal will sound and the display will indicate that the oven has reached the set temperature, requiring to "ADD FOOD". At this point, open the door, place the food in the oven, close the door and start cooking by pressing  or  .

Please note: Placing the food in the oven before preheating has finished may have an adverse effect on the final cooking result. Opening the door during the preheating phase will stop pause it.

The cooking time does not include a preheating phase. You can always change the temperature you want the oven to reach using  $+$  or  $-$  .

## 6. TURN OR CHECK FOOD

Some My Menu functions will require the food to be turned during cooking.



An audible signal will sound and the display shows the action to be done. Open the door, do the action prompted by the display and close the door, then press  to continue cooking.

In the same way, at 10% of time before the end of cooking, the oven prompts you to check the food.




An audible signal will sound and the display shows the action to be done. Check the food, close the door and press  or  to continue cooking.

Please note: Press  to skip these actions. Otherwise, if no action is done after a certain time the oven will continue the cooking.

## 7. END OF COOKING


An audible signal will sound and the display will indicate that cooking is complete.



Press  to continue cooking in manual mode (untimed) or press  $+$  to extend the cooking time by setting a new duration. In both cases, the cooking parameters will be retained.

## BROWNING


Some functions of the oven enable you to brown the surface of the food by activating the grill once cooking is complete.



When the display shows the relevant message, if required press  to start a five-minute browning cycle. You can stop the function at any time by pressing  to switch the oven off.

## 8. FAVORITES

Once cooking is complete the display will prompt you to save the function in a number between 1 and 10 on your list of favorites.



If you would like to save a function as a favorite and store the current settings for future use, press  otherwise, to ignore the request press  $\ll$  .

Once  has been pressed, press the  $+$  or  $-$  to select the number position, then press  to confirm.

Please note: If the memory is full or the number chosen has already been taken, the oven will ask you to confirm overwriting the previous function.

To call up the functions you have saved at a later time, press  $\star$  : The display will show your list of favorite functions.



Press  $+$  or  $-$  to select the function, confirm by pressing  , and then press  to activate.

## 9. CLEANING

### • PYRO

**Do not touch the oven during the Pyro cycle. Keep children and animals away from the oven during and after (until the room has finished airing) running the Pyro cycle.**

Remove all accessories - including shelf guides - from the oven before activating the function. If the oven is installed below a hob, make sure that all the burners or electric hotplates are switched off while running the selfcleaning cycle. For optimum cleaning results, remove the worst soiling with a damp sponge before using the Pyro function. We recommend only running the Pyro function if the appliance contains heavy soiling or gives off bad odours during cooking.

Press  to show "Pyro" on the display.






Press  $+$  or  $-$  to select the desired cycle, then press  $\checkmark$  to confirm. Once a cycle has been selected, if desired, press  $+$  or  $-$  to set end time (start delay), then press  $\checkmark$  to confirm.

Clean the door and remove all accessories as prompted, then close the door and press  $\triangleright$  when done: the oven will begin the self-cleaning cycle, while the door locks automatically: a warning message appears on the display, along with a countdown indicating the status of the cycle in progress.

Once the cycle has been completed, the door remains locked until the temperature inside the oven has returned to a safe level.

#### • DIAMOND CLEAN

Press  $\text{⏏}$  to show "Diamond Clean" on the display.




Press  $\triangleright$  to activate the function: the display will prompt you to do all actions needed to obtain the best cleaning results: Follow the indications and then press  $\checkmark$  when done. Once you have done all steps, when required press  $\triangleright$  to activate the cleaning cycle.

Please note: It is recommended to do not open the oven door during the cleaning cycle to avoid a loss of water vapor that could get an adverse effect on the final cleaning result.

An appropriate message will start flashing on the display once the cycle has finished. Leave the oven to cool and then wipe and dry the interior surfaces with a cloth or sponge.

#### 10. MINUTEMINDER

To activate this function press the  $\text{⌚}$  icon. Press  $+$  or  $-$  to set the length of time you require and then press  $\checkmark$  to activate the timer.



An audible signal will sound and the display will indicate once the minuteminder has finished counting down the selected time.

Please note: The minuteminder does not activate any of the cooking cycles.

The minute minder can be activated also when a function is running.

The timer will continue to count down independently without interfering with the function itself.

During this phase, it isn't possible to see the minuteminder (only the  $\text{⌚}$  icon will be displayed), that will continue counting down in background. To edit the

minuteminder you can press the  $\text{⌚}$  icon and set the time using the  $+$  or  $-$  icon.

To cancel the minuteminder, press the  $\text{⌚}$  icon, then select  $-$  until the time displayed is "--:--". Press  $\checkmark$  to confirm.

#### 11. KEYLOCK


To lock the keypad, press and hold  $\ll$  for at least five seconds. Do this again to unlock the keypad.



Please note: This function can also be activated during cooking. For safety reasons, the oven can be switched off at any time by pressing  $\text{⏏}$ .

#### • USING THE MEAT PROBE (IF PRESENT)

Using the probe enables you to measure the core temperature of the meat during cooking to ensure that it reaches the optimum temperature. The temperature of the oven varies according to the function that you have selected, but cooking is always programmed to finish once the specified temperature has been reached.



It is very important to position the probe accurately in order to obtain perfect cooking results. Insert the probe fully into the fleshiest part of the meat, avoiding bones and fatty parts. For poultry, the probe should be inserted sideways, in the middle of the breast, taking care to ensure the tip does not end up in a hollow part. In the case of meat with very irregular thickness, check it is

cooked properly before removing it from the oven. Connect the end of the probe in the hole located on the right wall of the oven cavity.

Once you have inserted the probe, an audible signal is activated and "Probe Plugged" appears on the display.




Select the function you require from those that are compatible (Conventional, Forced Air, Convection Bake, Turbogrill, Eco Forced Air, Maxi Cooking, MyMenu functions): The display prompts to set the target temperature of the probe: Press  $+$  or  $-$  to set it and press  $\checkmark$  to set the following cooking parameters.

As cooking is programmed to finish once the required temperature has been reached, it is not possible to set the cooking time or set a specific time for cooking to end. The light will remain switched on until the probe is removed.

If the probe is removed during cooking, it will continue by the traditional mode (untimed).

---

An audible signal will sound and the display will indicate when the probe has reached the required temperature.



Please note: To change the settings subsequently, press  $\oplus$  or  $\ominus$  for the probe temperature or press  $\ll$  for other settings. An audible signal and a message will tell you if use of the probe is not compatible with the action done. If this is the case, remove the probe.

#### **. NOTES**

- Do not cover the inside of the oven with aluminium foil.
- Never drag pots or pans across the bottom of the oven as this could damage the enamel coating.
- Do not place heavy weights on the door and do not hold on to the door.
- Due to the higher temperature of the Pizza cycle it is expected to experience slightly higher cooling fan noise.

---

## USEFUL TIPS

---

### HOW TO READ THE COOKING TABLE

The table lists the best function, accessories and level to use to cook different types of food. Cooking times start from the moment food is placed in the oven, excluding preheating (where required). Cooking temperatures and times are approximate and depend on the amount of food and the type of accessory used. Use the lowest recommended settings to begin with and, if the food is not cooked enough, then switch to higher settings. Use the accessories supplied and preferably dark-coloured metal cake tins and baking trays. You can also use Pyrex or stoneware pans and accessories, but bear in mind that cooking times will be slightly longer.

---

### COOKING DIFFERENT FOODS AT THE SAME TIME

Using the "Forced Air" function, you can cook different foods which require the same cooking temperature at the same time (for example: fish and vegetables), using different shelves. Remove the food which requires a shorter cooking time and leave the food which requires a longer cooking time in the oven.

---

### MEAT

Use any kind of oven tray or pyrex dish suited to the size of the piece of meat being cooked. For roast joints, it is best to add some stock to the bottom of the dish, basting the meat during cooking for added flavour. Please note that steam will be generated during this operation. When the roast is ready, let it rest in the oven for another 10-15 minutes, or wrap it in aluminium foil.

When you want to grill meat, choose cuts with an even thickness all over in order to achieve uniform cooking results. Very thick pieces of meat require longer cooking times. To prevent the meat from burning on the outside, lower the position of the wire shelf, keeping the food farther away from the grill. Turn the meat two thirds of the way through cooking. Take care when opening the door as steam will escape.

To collect the cooking juices, we recommend placing a dripping pan filled with half a litre of drinking water directly underneath the wire shelf on which the food is placed. Top-up when necessary.

### DESSERTS

Cook delicate desserts with the conventional function on one shelf only.

Use dark-coloured metal baking pans and always place them on the wire shelf supplied. To cook on more than one shelf, select the forced air function and stagger the position of the cake tins on the shelves, aiding optimum circulation of the hot air.

To check whether a leavened cake is cooked, insert a wooden toothpick into the centre of the cake. If the toothpick comes out clean, the cake is ready.

If using non-stick baking pans, do not butter the edges as the cake may not rise evenly around the edges.

If the item "swells" during baking, use a lower temperature next time and consider reducing the amount of liquid you add or stirring the mixture more gently.

For desserts with moist fillings or toppings (such as cheesecake or fruit tarts), use the "Convection bake" function. If the base of the cake is soggy, lower the shelf and sprinkle the bottom of the cake with breadcrumbs or biscuit crumbs before adding the filling.

---

### RISING

It is always best to cover the dough with a damp cloth before placing it in the oven. Dough proving time with this function is reduced by approximately one third compared to proving at room temperature (20-25°C). The rising time for pizza starts at around one hour for 1 kg of dough.






# MY MENU COOKING TABLE

| FOOD CATEGORIES |                | QUANTITY           | DONENESS LEVEL   | BROWNING LEVEL | TURN (OF COOK TIME) | LEVEL AND ACCESSORIES |      |
|-----------------|----------------|--------------------|------------------|----------------|---------------------|-----------------------|------|
| BAKED           | Main dishes    | Lasagna            | 0.5 - 3 kg       | -              | 0                   | -                     | 2    |
|                 |                | Salty cakes        | 0.8 - 1.2 kg     | -              | 0                   | -                     | 2    |
|                 |                | Stuffed Vegetables | 0.1 - 0.5 kg cad | -              | -                   | -                     | 3    |
|                 | Pizza & bread  | Bread Rolls        | 60 - 150g cad    | -              | -                   | -                     | 3    |
|                 |                | Sandwich Loaf      | 0.4 - 0.6kg cad  | -              | -                   | -                     | 2    |
|                 |                | Big Bread          | 0.7 - 2.0kg      | -              | -                   | -                     | 2    |
|                 |                | Baguettes          | 200 - 300g cad   | -              | -                   | -                     | 3    |
|                 |                | Round Pizza        | round            | -              | -                   | -                     | 2    |
|                 |                | Thick Pizza        | tray             | -              | -                   | -                     | 2    |
|                 |                | Pizza [frozen]     | 1 layer*         | -              | -                   | -                     | 2    |
|                 | 2 layers*      |                    | -                | -              | -                   | 4  1                  |      |
|                 | 3 layers*      |                    | -                | -              | -                   | 5  3  1               |      |
|                 | 4 layers*      |                    | -                | -              | -                   | 5  4  2  1            |      |
|                 | Sweet bakery   | Sponge Cake        | 0.5 - 1.2 kg     | -              | -                   | -                     | 2    |
|                 |                | Cookies            | 0.2 - 0.6 kg     | -              | -                   | -                     | 3    |
|                 |                | Choux Pastry       | one tray*        | -              | -                   | -                     | 3    |
|                 |                | Tart               | 0.4 - 1.6kg      | -              | -                   | -                     | 3    |
|                 |                | Strudel            | 0.4 - 1.6kg      | -              | -                   | -                     | 3    |
| Fruit Pie       |                | 0.5 - 2 kg         | -                | -              | -                   | 2                     |      |
| ROASTED         | Meat           | Roast Beef         | 0.6 - 2 kg*      | 0              | 0                   | -                     | 3    |
|                 |                | Roast Pork         | 0.6 - 2.5 kg*    | -              | 0                   | -                     | 3    |
|                 |                | Roast Chicken      | 0.6 - 3 kg*      | -              | 0                   | -                     | 2    |
|                 | Side dish      | Roasted Vegetables | 0.5 - 1.5 kg     | -              | 0                   | -                     | 3    |
|                 |                | Roasted Potatoes   | 0.5 - 1.5 kg     | -              | -                   | -                     | 3    |
| GRILLED         | Meat           | Burger             | 1.5 - 3 cm       | 0              | -                   | 3/5                   | 5  4 |
|                 |                | Sausages & Wurstel | 1.5 - 4 cm       | -              | -                   | 2/3                   | 5  4 |
|                 |                | Kebabs             | one grid         | -              | -                   | 1/2                   | 5  4 |
|                 |                | Fillet & Breast    | 1 - 5 cm         | -              | -                   | 2/3                   | 5  4 |
|                 | Fish & seafood | Fillets            | 0.5 - 3 (cm)     | -              | -                   | -                     | 3  2 |
|                 |                | Fillets [frozen]   | 0.5 - 3 (cm)     | -              | -                   | -                     | 3  2 |
| ROASTED         |                | Whole fish         | 0.2 - 1.5 kg*    | -              | -                   | -                     | 3  2 |






\* Suggested quantity

| ACCESSORIES |            |                                      |                         |                                |            |
|-------------|------------|--------------------------------------|-------------------------|--------------------------------|------------|
|             | Wire shelf | Oven tray or cake tray on wire shelf | Drip tray / Baking tray | Drip tray with 500 ml of water | Food Probe |

# MY MENU COOKING TABLE

| FOOD CATEGORIES |           | QUANTITY           | DONENESS LEVEL | BROWNING LEVEL | TURN (OF COOK TIME) | LEVEL AND ACCESSORIES |  |
|-----------------|-----------|--------------------|----------------|----------------|---------------------|-----------------------|--|
| GRILLED         | SIDE DISH | Tomatoes Gratin    | one tray       | -              | -                   | -                     | 3<br> |
|                 |           | Peppers Gratin     | one tray       | -              | -                   | -                     | 3<br> |
|                 |           | Broccoli Gratin    | one tray       | -              | -                   | -                     | 3<br> |
|                 |           | Cauliflower Gratin | one tray       | -              | -                   | -                     | 3<br> |
|                 |           | Vegetables Gratin  | one tray       | -              | -                   | -                     | 3<br> |

\* Suggested quantity

|             |   |   |  |   |   |
|-------------|---|---|--|---|---|
| ACCESSORIES | <br>Wire shelf | <br>Oven tray or cake tray on wire shelf | <br>Drip tray / Baking tray | <br>Drip tray with 500 ml of water | <br>Food Probe |
|-------------|---|---|--|---|---|



# AIR FRY COOKING TABLE

|               | RECIPE                 | FUNCTION | SUGGESTED QUANTITY | PREHEAT | TEMPERATURE (°C) | DURATION (MIN.) | SHELF AND ACCESSORIES |
|---------------|------------------------|----------|--------------------|---------|------------------|-----------------|-----------------------|
| FROZEN FOOD   | Frozen French Fries    |          | 650 - 850g         | Yes     | 200              | 25 - 30         | 4  2                  |
|               | Frozen Chicken Nugget  |          | 500g               | Yes     | 200              | 15 - 20         | 4  2                  |
|               | Fish Sticks            |          | 500g               | Yes     | 220              | 15 - 20         | 4  2                  |
|               | Onion Rings            |          | 500g               | Yes     | 200              | 15 - 20         | 4  2                  |
| VEGETABLES    | Fresh Breaded Zucchini |          | 400g               | Yes     | 200              | 15 - 20         | 4  2                  |
|               | Homemade Fries         |          | 300 - 800 g        | Yes     | 200              | 20 - 40         | 4  2                  |
|               | Mixed Vegetables       |          | 300 - 800 g        | Yes     | 200              | 20 - 30         | 4  2                  |
| MEAT AND FISH | Chicken Breasts        |          | 1 - 4 cm           | Yes     | 200              | 20 - 40         | 4  2                  |
|               | Chicken Wings          |          | 200 - 1500 g       | Yes     | 220              | 30 - 50         | 4  2                  |
|               | Breaded Cutlet         |          | 1 - 4 cm           | Yes     | 220              | 20 - 50         | 4  2                  |
|               | Fish Fillet            |          | 1 - 4 cm           | Yes     | 220              | 15 - 25         | 4  2                  |

For cooking fresh or homemade foods, spread a thin layer of oil across the food surface.  
In order to guarantee uniform cooking results, mix food halfway through the recommended cooking time.

|             |                  |  |  |
|-------------|------------------|--|--|
| FUNCTIONS   | <br>Air Fry      |  |  |
| ACCESSORIES | <br>Air Fry tray | <br>Oven tray or cake tray on wire shelf | <br>Drip tray / Baking tray or oven tray on wire shelf |

# COOKING TABLE

| RECIPE   | FUNCTION | PREHEAT | TEMPERATURE (°C) | DURATION (MIN.) | SHELF AND ACCESSORIES |
|--|----------|---------|------------------|-----------------|-----------------------|
| Leavened cakes / Sponge cakes                    |          | Yes     | 170              | 30 - 50         |                       |
|  |          | Yes     | 160              | 30 - 50         |                       |
|  |          | Yes     | 160              | 30 - 50         |                       |
| Filled cakes<br>(cheesecake, strudel, apple pie) |          | Yes     | 160 - 200        | 30 - 85         |                       |
|  |          | Yes     | 160 - 200        | 30 - 90         |                       |
| Cookies  |          | Yes     | 150              | 20 - 40         |                       |
|  |          | Yes     | 140              | 30 - 50         |                       |
|  |          | Yes     | 140              | 30 - 50         |                       |
|  |          | Yes     | 135              | 40 - 60         |                       |
| Small cakes / Muffin                             |          | Yes     | 170              | 20 - 40         |                       |
|  |          | Yes     | 150              | 30 - 50         |                       |
|  |          | Yes     | 150              | 30 - 50         |                       |
|  |          | Yes     | 150              | 40 - 60         |                       |
| Choux buns                                       |          | Yes     | 180 - 200        | 30 - 40         |                       |
|  |          | Yes     | 180 - 190        | 35 - 45         |                       |
|  |          | Yes     | 180 - 190        | 35 - 45 *       |                       |
| Meringues  |          | Yes     | 90               | 110 - 150       |                       |
|  |          | Yes     | 90               | 130 - 150       |                       |
|  |          | Yes     | 90               | 140 - 160 *     |                       |
| Pizza / Bread / Focaccia                         |          | Yes     | 190 - 250        | 15 - 50         |                       |
|  |          | Yes     | 190 - 230        | 20 - 50         |                       |
| Pizza (Thin, thick, focaccia)                    |          | Yes     | 310              | 7 - 12          |                       |
|  |          | Yes     | 220 - 240        | 25 - 50 *       |                       |
| Frozen pizza                                     |          | Yes     | 250              | 10 - 15         |                       |
|  |          | Yes     | 250              | 10 - 20         |                       |
|  |          | Yes     | 220 - 240        | 15 - 30         |                       |
| Savoury pies<br>(vegetable pie, quiche)          |          | Yes     | 180 - 190        | 45 - 55         |                       |
|  |          | Yes     | 180 - 190        | 45 - 60         |                       |
|  |          | Yes     | 180 - 190        | 45 - 70 *       |                       |

| FUNCTIONS   |              |                                      |                 |  |             |                         |                | ECO                            |       |
|-------------|--------------|--------------------------------------|-----------------|--|-------------|-------------------------|----------------|--------------------------------|-------|
|             | Conventional | Forced Air                           | Convection Bake | Grill  | Turbo Grill | MaxiCooking             | Multiflow Menu | Eco Cycle                      | Pizza |
| ACCESSORIES |              |                                      |                 |  |             |                         |                |                                |       |
|             | Wire shelf   | Oven tray or cake tray on wire shelf |                 | Drip tray / Baking tray or oven tray on wire shelf |             | Drip tray / Baking tray |                | Drip tray with 500 ml of water |       |

| RECIPE  | FUNCTION | PREHEAT | TEMPERATURE (°C)   | DURATION (MIN.) | SHELF AND ACCESSORIES |
|---|----------|---------|--------------------|-----------------|-----------------------|
| Vols-au-vent / Puff pastry crackers   |          | Yes     | 190 - 200          | 20 - 30         |                       |
|   |          | Yes     | 180 - 190          | 20 - 40         |                       |
|   |          | Yes     | 180 - 190          | 20 - 40 *       |                       |
| Lasagna / Flans / Baked pasta / Cannelloni  |          | Yes     | 190 - 200          | 45 - 65         |                       |
| Lamb / Veal / Beef / Pork 1 kg  |          | Yes     | 190 - 200          | 80 - 110        |                       |
| Roast pork with crackling 2 kg  |          | -       | 170                | 110 - 150       |                       |
| Chicken / Rabbit / Duck 1 kg  |          | Yes     | 200 - 230          | 50 - 100        |                       |
| Turkey / Goose 3 kg   |          | Yes     | 190 - 200          | 80 - 130        |                       |
| Baked fish / en papillote (fillets, whole)  |          | Yes     | 180 - 200          | 40 - 60         |                       |
| Stuffed vegetables (tomatoes, courgettes, aubergines)   |          | Yes     | 180 - 200          | 50 - 60         |                       |
| Toast   |          | -       | 3 (High)           | 3 - 6           |                       |
| Fish fillets / Steaks   |          | -       | 2 (Mid)            | 20 - 30 **      |                       |
| Sausages / Kebabs / Spare ribs / Hamburgers   |          | -       | 2 - 3 (Mid - High) | 15 - 30 **      |                       |
| Roast chicken 1-1.3 kg  |          | -       | 2 (Mid)            | 55 - 70 ***     |                       |
| Leg of lamb / Shanks  |          | -       | 2 (Mid)            | 60 - 90 ***     |                       |
| Roast potatoes  |          | -       | 2 (Mid)            | 35 - 55 ***     |                       |
| Vegetable gratin  |          | -       | 3 (High)           | 10 - 25         |                       |
| Cookies   |          | Yes     | 135                | 50 - 70         |                       |
| Tarts   |          | Yes     | 170                | 50 - 70         |                       |
| Round pizzas  |          | Yes     | 210                | 40 - 60         |                       |
| Complete meal: Fruit tart (level 5) / lasagna (level 3) / meat (level 1)  |          | Yes     | 190                | 40 - 120 *      |                       |
| Complete meal: Fruit tart (level 5) / roasted vegetables (level 4) / lasagna (level 2) / cuts of meat (level 1) |          | Yes     | 190                | 40 - 120 *      |                       |
| Lasagna & Meat  |          | Yes     | 200                | 50 - 100 *      |                       |
| Meat & Potatoes   |          | Yes     | 200                | 45 - 100 *      |                       |
| Fish & Vegetables   |          | Yes     | 180                | 30 - 50 *       |                       |
| Stuffed roasting joints   | ECO      | -       | 200                | 80 - 120 *      |                       |
| Cuts of meat (rabbit, chicken, lamb)  | ECO      | -       | 200                | 50 - 100 *      |                       |

\* Estimated length of time: dishes can be removed from the oven at different times depending on personal preference.

\*\* Turn food halfway through cooking.

\*\*\* Turn food two thirds of the way through cooking (if necessary).

| FUNCTIONS   |              |                                      |  |                         |                         |                                |                | ECO       |       |
|-------------|--------------|--------------------------------------|--|-------------------------|-------------------------|--------------------------------|----------------|-----------|-------|
|             | Conventional | Forced Air                           | Convection Bake                                    | Grill                   | Turbo Grill             | MaxiCooking                    | Multiflow Menu | Eco Cycle | Pizza |
| ACCESSORIES |              |                                      |  |                         |                         |                                |                |           |       |
|             | Wire shelf   | Oven tray or cake tray on wire shelf | Drip tray / Baking tray or oven tray on wire shelf | Drip tray / Baking tray | Drip tray / Baking tray | Drip tray with 500 ml of water |                |           |       |



## HOW TO READ THE COOKING TABLE

The table lists the best function, accessories and level to use to cook different types of food.

Cooking times start from the moment food is placed in the oven, excluding preheating (where required).

Cooking temperatures and times are approximate and depend on the amount of food and the type of accessory used. Use the lowest recommended settings to begin with and, if the food is not cooked enough, then switch to higher settings.

Use the accessories supplied and preferably darkcoloured metal cake tins and baking trays. You can also use Pyrex or stoneware pans and accessories, but bear in mind that cooking times will be slightly longer.

## CLEANING AND MAINTENANCE

**Make sure that the oven has cooled down before carrying out any maintenance or cleaning.**

**Do not use steam cleaners.**

**Do not use wire wool, abrasive scourers or abrasive/corrosive cleaning agents, as these could damage the surfaces of the appliance.**

**Wear protective gloves.**

**The oven must be disconnected from the mains before carrying out any kind of maintenance work.**

### EXTERIOR SURFACES

• Clean the surfaces with a damp microfibre cloth. If they are very dirty, add a few drops of pH-neutral detergent. Finish off with a dry cloth.

• Do not use corrosive or abrasive detergents. If any of these products inadvertently comes into contact with the surfaces of the appliance, clean immediately with a damp microfibre cloth.

### INTERIOR SURFACES

• After every use, leave the oven to cool and then clean it, preferably while it is still warm, to remove any deposits or stains caused by food residues. To dry any condensation that has formed as a result of cooking foods with a high water content, leave the oven to cool completely and then wipe it with a cloth or sponge.

• Activate the "Diamond Clean" function for optimum cleaning of the internal surfaces. (Only in some models).

• Clean the glass in the door with a suitable liquid detergent.

• The oven door can be removed to facilitate cleaning.

### ACCESSORIES

Soak the accessories in a washing-up liquid solution after use, handling them with oven gloves if they are still hot. Food residues can be removed using a washing-up brush or a sponge.

Do not clean Food Probe and Meat Probe (if present) in the dishwasher. Air Fry tray (if present) can be cleaned in the dishwasher.

## REPLACING THE LAMP

**1.** Disconnect the oven from the power supply.

**2.** Unscrew the cover from the light, replace the bulb and screw the cover back on the light.

**3.** Reconnect the oven to the power supply.


Please note: 40 W/230 ~ V type G9, T300°C halogen bulbs.

The bulb used in the product is specifically designed for domestic appliances and is not suitable for general room lighting within the home. (EC Regulation 244/2009) Light bulbs are available from our After-sales Service.


If using halogen bulbs, do not handle them with your bare hands as your fingerprints could cause damage. Do not use the oven until the light cover has been refitted.

## REMOVING AND REFITTING THE DOOR

**1.** To remove the door, open it fully and lower the catches until they are in the unlock position.




**2.** Close the door as much as you can. Take a firm hold of the door with both hands – do not hold it by the handle. Simply remove the door by continuing to close it while pulling it upwards at the same time until it is released from its seating. Put the door to one side, resting it on a soft surface.




**3.** Refit the door by moving it towards the oven, aligning the hooks of the hinges with their seating and securing the upper part onto its seating.

**4.** Lower the door and then open it fully. Lower the catches into their original position: Make sure that you lower them down completely.



Apply gentle pressure to check that the catches are in the correct position.




**5.** Try closing the door and check to make sure that it lines up with the control panel. If it does not, repeat the steps above: The door could become damaged if it does not work properly.

# TROUBLESHOOTING

| Problem  | Possible cause   | Solution  |
|--|--|---|
| The oven is not working.   | Power cut.<br>Disconnection from the mains.  | Check for the presence of mains electrical power and whether the oven is connected to the electricity supply.<br>Turn off the oven and restart it to see if the fault persists. |
| The display shows the letter "F" followed by a number.                                       | Software problem.  | Contact the Call Center and state the number following the letter "F".  |
| The oven does not heat up.   | When "DEMO" is "On" all commands are active and menus available but the oven doesn't heat up.<br>DEMO appears on display every 60 seconds. | Access "DEMO" from "SETTINGS" and select "Off".   |
| The light switches off.  | "ECO" mode is "On".  | Access "ECO" from "SETTINGS" and select "Off".  |
| The door will not close properly.  | The safety catches are in the wrong position.  | Make sure that the safety catches are in the correct position by following the instructions for removing and refitting the door in the "Cleaning and Maintenance" section.      |
| The home power goes off.   | Power setting wrong.   | Verify if your domestic network has at least a rating of more than 3 kW. If no, decrease the power to 13 Ampere. Access "POWER" from "SETTINGS" and select "LOW".               |
| Cooking cycle with probe ended without evident cause or error F3E3 is printed on the screen. | Food Probe is not properly connected.  | Check connection of the food probe.   |

**Policies, standard documentation and additional product information can be found by:**

- Using the QR on your product
- Visiting our website [docs.hotpoint.eu](https://docs.hotpoint.eu)
- Alternatively, **contact our After-sales Service** (See phone number in the warranty booklet). When contacting our After-sales Service, please state the codes provided on your product's identification plate.



**Hotpoint**



**400020027000**