

For recipes and ideas, visit:



# KitchenAid

ENGLISH

## Pastry Beater

**5KSMPB5, 5KSMPB5SS, and 5KSMPB5W:** This accessory has been approved for use with all 4.3 L and 4.8 L KitchenAid Tilt Head Stand Mixers.

**5KSMPB7, 5KSMPB7SS, and 5KSMPB7W** - Compatible with all KitchenAid Bowl-Lift Stand Mixers except for models 5KPM5, 5K5, 4KSM5, 5K5SS, 5KSM5, 5KSM50, 5KSM500, 5KSM6573, KG25, 3KSM5, 9KSM5, and 5KSM450. Only approved for bowl lift use with Stainless Steel bowls.

## IMPORTANT SAFEGUARDS

**When using electrical appliances, basic safety precautions should always be followed. Please refer to the basic Important Safeguards as outlined in the manual for your Stand Mixer.**

**Note:** 5KSMPB5, 5KSMPB5SS, 5KSMPB5W, 5KSMPB7, and 5KSMPB7W are designed for household use only.

Refer to Product Assembly section of your Stand Mixer owner's manual for assembly instructions for accessories.

## CARE AND CLEANING

1. During use: Stop the mixer and scrape beater with a spatula.
2. After use: Top-rack dishwasher safe.

Refer to the guarantee and conditions included in the owner's manual of the Stand Mixer or at [www.KitchenAid.eu](http://www.KitchenAid.eu)

To see the warranty, scan the QR code and enter the model number into the search bar:



©2021 All rights reserved.

KITCHENAID and the design of the Stand Mixer are trademarks in the U.S. and elsewhere.