



1. Rapid hotplate Ø 180 - 2000 W
2. Normal hotplate Ø 145 - 1000 W
3. Normal hotplate Ø 180 - 1500 W
4. Normal hotplate Ø 145 - 1000 W
5. Rapid hotplate control knob Ø 180 ☒
6. Normal hotplate control knob Ø 145 ☒
7. Normal hotplate control knob Ø 180 ☒
8. Normal hotplate control knob Ø 145 ☒
9. Hotplate operation control lamp ~




### Operation of electric hotplates

- Set the knob to one of positions 1-6, which correspond to different temperatures.
- To switch off the hotplate, set the knob to position "0".

# DIMENSIONS OF COOKTOP AND WORKTOP



**N.B.:** In case of installation of a hood above the cooktop, please refer to the hood instructions for the correct distance.

SUPPLY VOLTAGE	CONDUCTORS: NUMBER AND SIZE	ELECTRICAL CONNECTION
230V ~ + 	3 x 2.5 mm <sup>2</sup>	<div> <div>1</div> <div>2</div> <div>3</div> <div>  </div> </div> <div> <div>○</div> <div>○</div> <div>○</div> <div>  </div> </div> <div> <div>L</div> <div></div> <div>N</div> </div>

**TYPE: PLETP 230V ~ 50Hz 5.5kW**