



Neutralizes bad odours



Refreshes

DeoDish - Dishwasher freshener • Display 16 pcs

The optimal solution to remove unpleasant odours from your dishwasher

CHARACTERISTICS

The dishwasher freshener DeoDish **neutralises odours and leaves a fresh scent of lemon or marine** every time you open your dishwasher. It also works between washes. Thanks to its user friendly clip, it is **easy to install** by fixing it directly onto the upper shelf of your dishwasher. Once attached use your dishwasher as normal, the liquid will gradually decrease.

THE RECOMMENDATION OF WPRO

Replace the whole DeoDish when the liquid is over (approximately after 60 washes).

CODES

DWD018 484000008894 C00424840 8015250603163
DWD020 484000008918 C00480694 8015250610451

LANGUAGES

EN / FR / NL / IT

LOGISTIC INFORMATION

	LxHxW (cm)	Weight (Kg)	Qty
Product:	8x19x3	0.025	1
SubPack:	17x20x27	0.4	16
Pallet:	80x120x100	35.6	896

CONSUMER BENEFIT

- **Universal:** suitable for use on all dishwashers of all brands
- **Easy to install:** Thanks to its user friendly clip, it is easy to install by xing it directly onto the upper shelf of your dishwasher
- **Double action:** neutralises odours and leaves a fresh scent of lemon or marine



Safety Data Sheet
available for this product