

شكراً على شرائك أحد منتجات شركة Whirlpool.

للحصول على مساعدة كاملة،

يرجى تسجيل جهازك على الموقع

www.whirlpool.eu/register




قبل استخدام الجهاز، احرص على قراءة إرشادات الأمان بعناية.
قبل استخدام الغسالة، يلزم خلع براغي الغفل.
لمزيد من التعليمات الفنية عن كيفية خلعهم، انظر دليل التركيب.



لوحة التحكم

- قفل المفاتيح مفعل = 0
- مرحلة الغسل ↗ تشير إلى مرحلة الغسل بالدوره
- خطأ: اتصال بالخدمة ↗ راجع جزء التغلب على الأعطال
- خطأ: انسداد فلتر الماء ↗ لا يمكن تصريف الماء، قد يكون فلتر الماء مسدودا
- خطأ: لا يوجد ماء ↗ الماء الداخل غير كافٍ أو غير موجود.
- في حالة حدوث لفائف الات، يرجى اللجوء إلى جزء "التغلب على الأعطال"



- 1 زر "التشغيل/إيقاف" ⏹
 - 2 مقناع اختيار البرنامج
 - 3 زر "بدء التشغيل/إيقاف المؤقت" ⏷
 - 4 زر "العصر" ⏴
 - 5 زر "تأخير بدء التشغيل" ⏵ + FreshCare
 - 6 قفل المفاتيح ⏵
 - 7 زر "درجة الحرارة" ⏵ °C المؤشرات بوحدة العرض
- باب مغلق ⌂ وظيفة FreshCare + مفعلة ⌂ تأخير بدء التشغيل مفعل ⌂

مخطط البرامج

نوع الماء بالتنفس العاملي	استهلاك الطاقة بالكلمولة *%	الطاقة المنبوبة *%	مواد التنظيف الموصى بها	المنظفات والإضافات			الكمية القصوى 7 كجم استهلاك الطاقة في وضع الإيقاف هو 0.5 واط/في وضع الترك مشغلاً هو 8.0 واط	درجات الحرارة	البرنامج		
				سائل	مسحوق	غسل أولي					
—	—	—	✓	—	○	●	—	**	3.5	1000 °40 - *	مختلط
—	—	—	✓	✓	○	●	(°90) ●	**	7.0	1000 °90 - *	ملابس بيضاء (1)
75	0.98	62	✓	✓	○	●	—	220	7.0	1000 °60 - *	أقطان
49	0.89	62	✓	✓	○	●	—	275	7.0	1000 °60 - *	أقطان (2)
—	—	—	✓	—	○	●	—	**	3.5	600 °40 - *	رياضية
—	—	—	✓	—	○	●	—	**	2.0	1000 °30 - *	الحفة
—	—	—	✓	—	○	●	—	**	3.5	800 °40 - *	جينز
—	—	—	—	—	—	—	—	**	7.0	1000 —	عصر وتصريف
—	—	—	—	—	○	—	—	**	7.0	1000 —	شطف وعصر
—	—	—	✓	—	○	●	—	**	3.0	800 °30 - *	سرع 30°
—	—	—	✓	—	○	●	—	**	3.5	1000 °15	Colours 15°
—	—	—	✓	—	○	●	—	**	1.5	800 °40 - *	أصوات
—	—	—	✓	—	○	●	—	**	1.0	— °30 - *	حساس
72	0.75	33	✓	✓	○	●	—	195	4.0	1000 °60 - *	ألياف صناعية

المعايير ضرورية ○ المعايير اختيارية ●

1) دورة الغسل الاختبارية وفقاً للوائح: UAE.S 5010-2: 2019

اصبِطْ برنامج الغسل ⏹ على درجة حرارة 60 درجة مئوية للقطن القياسي 60 درجة مئوية.

برنامج أقطان - دورات غسل مختلفة طبقاً للوائح المعايرة 2010/601/EC وهي بمثابة برنامج مرجعية لمجلس الطاقة. اصيُّطْ درجة حرارة دورات الغسل هذه على 60 °C. وتعد هذه البرامج هي الأكثر كفاءة فيما يتعلق بارتفاع الطاقة والماء عند غسل الملابس القطبية ذات الاتصالات العادي. وقد تختلف درجة الحرارة الفعلية عن درجة المعلن عنها في الجدول.


يسري على جميع معايير اختبار الغسل طبقاً للوائح المعايرة 2010/601/EC.

دورات غسل طولية للأقطان: اصيُّطْ درجة حرارة غسل برنامج أقطان على درجة حرارة 40 °C.

برنامج الألياف الصناعية طول الوقت: اصيُّطْ درجة حرارة الماء المسحوب على درجة حرارة 40 °C. قد تختلف هذه البيانات عما هو عليه الحال في منزلك نظراً لتغير الظروف المتعلقة بدرجة حرارة الماء المسحوب وضغط الماء والخلف. تشير أسماء البرامج التقليدية إلى وضع الضبط الأساسي للبرامج، دون اختيار وظائف اختيارية.

شرح المنتج

1. سطح العمل
2. درج مادة الغسل
3. لوحة التحكم
4. مقبض الباب
5. الباب
6. فلتر الماء - خلف القاعدة
7. قاعدة (قابلة للخلع)
8. أرجل قابلة للضبط (4)



درج مادة الغسل

حجزة الغسل الرئيسي

حجزة للغسل الرئيسي، مزيل البقع أو منعم الماء. بالنسبة للمنظفات السائلة تناصح باستخدام الدرج البلاستيكي القابل للخلع (مورد) لضمان المعايرة الصحيحة.

وفي حالة استخدام مسحوق تنظيف، أدخل الدرج في الفتحة B.

حجزة الغسل الأولي

مادة الغسل الخاصة بالغسل الأولي.


حجزة المنعم

منعم الملابس. تشا سائل.

فقط

زر التحرير ➔

اضغط لإزالة الدرج لتنظيفه.





لاختيار البرنامج المناسب لنوع الغسيل، احرص دائمًا على اتباع التعليمات الموضحة على تيكيتات العناية الموجودة على الملابس. القيمة المبينة على رمز الحوض تعبّر عن درجة الحرارة الصاروخي لغسل قطعة الملابس.

مختلط
لغسل قطع الملابس المطاطية خفيفة إلى متوسطة الاتساخ من القطن أو الكتان أو الألياف الصناعية والألياف المختلطة.

ملابس بيضاء
لغسل الملابس الداخلية والملابس الماء والأسرة وغيرها ذات الاتساخات العادية حتى الشديدة والمصنوعة من القطن أو الكتان. يتم تزويذ الدورة بمراحل غسل أولى قبل مرحلة الغسل الأساسي فقط في حالة ضبط درجة الحرارة على 90°م. وفي هذه الحالة نوصي بإضافة مادة التنظيف في كلا الدورتين، الغسل الأولي والغسل الأساسي.

أقطان
الملابسقطنية الثقيلة ذات الاتساخات العادية حتى الشديدة.

أقطان
لغسل الملابسقطنية ذات الاتساخات العادية. برنامج قياسي للملابسقطنية عند درجة حرارة 60°م وأكثرها كفاءة فيما يتعلق باستهلاك الماء والطاقة.

ملابس رياضية
لغسل الملابس الرياضية المتسخة بعض الشيء (البدلات الرياضية والسارويل الصغيرة وغيرها). وننصح بعدم تجاوز الكميةقصوى الموضحة في "مخطط البرنامج" للحصول على أفضل النتائج. كما ننصح باستخدام مواد التنظيف السائلة وإضافة الكمية المناسبة لنصف كمية الغسيل.

الحفة
برنامج مصمم لغسل القطع المبطنة بالريش مثل الألحاف ثنائية أو أحادية الطبقية، الوسادات والمعاطف. ننصح بوضع الملابس المبطنة في الحلة بحيث تكون أطرافها مطوية للداخل ولا تتعدى مقدار 3% من مساحة الحلة. ونوصيك باستخدام المنظفات السائلة للحصول على نتائج غسل مثالية.

جيبيز
قلب الملابس قبل غسلها واستخدم منظفات سائلة.

عصر وتصريف
يقوم بعصير كمية الغسيل وتصريف الماء بعد ذلك. الملابس المرنة. سوف يقوم الجهاز بالتصريف فقط إذا كنت باستبعاد دورة العصر.

شفط وعصر
تقوم بالشفط ثم العصر. للملابس المرنة.

سريع 30°
لغسل الملابس ذات الاتساخات الخفيفة بسرعة. تستغرق هذه الدورة لمدة 30 دقيقة، وتتناسب بتوفير الوقت والطاقة.

أصوات 15°
تساهم هذه الدورة في حماية الملابس الملونة عند الغسل في الماء البارد (15°م) وتستخدم أقل مقدار من الطاقة لتسخين الماء في ظل تحقيق نتائج غسل مرتبطة للملابس المتسخة بغض الشيء وغير المشتملة على بقع. وتحقق هذه الدورة نتائج غسل مماثلة لدورة غسل كمية مختلطة بدرجة 40°م عند 15°م فقط.

أصوات
باستخدام برنامج "أصوات" يمكن غسل جميع الملابس الصوفية حتى التي تحمل التكبير "غسل يدوي فقط". وللحصول على أفضل النتائج، استخدم مواد التنظيف المخصصة ولا تتعدى كمية الغسيلقصوى المحددة بالكيلو الجرام والموضحة في الجدول.

حساس
لغسل الملابس شديدة الحساسية. من الأفضل قلب الملابس قبل غسلها.

اليافصناعية
لغسل الملابس المتسخة المصنوعة من الألياف الصناعية (مثل البوليستر أو البولي أكريليك أو الفيسكون، إلخ) أو الأقمشة القطنية/الصناعية المختلطة.

الاستخدام لأول مرة

للخلص من آية شوائب ناتجة عن التصنيع، اختار برنامج "أقطان" في درجة حرارة 60°م. ضع كمية صغيرة من مسحوق الغسل في حجيرة الغسل الرئيسية بدرج مادة الغسل (بعد إضافة 1/3 الكمية الموصى بها من قبل الجهة الصانعة لمادة الغسل للغسيل المتعدد بدرجة حرارة 60°م). ابدأ تشغيل البرنامج دون إضافة غسيل.

الاستخدام اليومي

قم بتحضير الغسيل وفقاً للتوصيات الواردة في جزء «إرشادات ونصائح». ضع الغسيل وأغلق الباب ثم افتح صنبور الماء واضغط على زر «التشغيل/الإيقاف» (لتشغيل الغسالة، فيومض الزر «بدء التشغيل/الإيقاف المؤقت»). ادر مفتاح اختيار البرنامج إلى البرنامج المرغوب واختار الوظيفة الاختيارية المطلوبة. يمكن تغيير درجة الحرارة وعدد لفات العصر بالضغط على زر «درجة الحرارة» °C أو زر «الصبر» Ⓛ. اسحب درج مادة الغسل وأضف مادة الغسل إليه (والإضافات/المنعم) عندئذ. تراعي المعالجات الموصى بها على عبوة مادة الغسل. بعد ذلكأغلق درج مادة الغسل.

اضغط على زر التشغيل/الإيقاف المؤقت.

ستغلق الغسالة الباب (الرمز ⓘ مضيء) وستبدأ الحلة في الدوران؛ وسيفتح الباب (الرمز ⓘ مطفأ) ثم يعلق مرة أخرى (الرمز ⓘ مضيء) كمرحلة تحضير لكل دورة غسيل. وصوت «الطقفقة» جزء من آلية قفل الباب. سيدخل الماء إلى الحلة وتندى الباب. سيدخل الماء إلى الحلة باباً لف در جمب لسغاً ملائم أبداً.

إيقاف البرنامج المشغّل بشكل مؤقت

اضغط على الزر «بدء التشغيل/الإيقاف المؤقت» (لإيقاف دورة الغسل مؤقتاً، ستنتهي لمبة المبين ويومض الوقت المتبقى على وحدة العرض. أعد الضغط على الزر لاستئناف تشغيل دورة الغسل من اللحظة التي توفر عندها).

فتح الباب عند التزوم

بعد بدء تشغيل برنامج، يضيء مبين "تأمين قفل الباب" ⓘ للإشارة إلى عدم إمكانية فتح الباب. ويبيّن الباب مؤمناً القفل طوال مدة تشغيل البرنامج. لفتح الباب أثناء تشغيل برنامج ما، أضفغ على زر «بدء التشغيل/الإيقاف المؤقت» (لإيقاف البرنامج مؤقتاً). إذا لم يكن مستوى الماء وأو درجة الحرارة مرتفعة للغاية، تنتهي لمبة مبين "تأمين قفل الباب" ⓘ ويمكنك فتح الباب عندئذ. بالإضافة أو إخراج غسيل على سبيل المثال. اضغط على زر "بدء التشغيل/الإيقاف المؤقت" ⓘ مجدداً لمواصلة البرنامج.

انتهاء البرنامج

ينطفئ مبين "تأمين قفل الباب" ⓘ ويظهر في وحدة العرض البيان "End". لإيقاف الغسالة بعد انتهاء البرنامج اضغط على الزر "التشغيل/الإيقاف" ⓘ وستنطفئ لمبة المبين المائية. إذا لم تضف سعّة تفريبياً. أغلق صنبور الماء، افتح الباب وأخرج الغسيل من الغسالة. اترك الباب مفتوحاً بشكل جزئي، للسماع بتجفيف الحلة.

الوظائف الاختيارية

!
إذا لم تتوافق الوظيفة الاختيارية المحددة مع البرنامج المصبوط، سيتم الإشارة إلى عدم التوافق من خلال صوت إنذار (3 صافرات) وستنضم لمبة المبين المعنية.
إذا لم تتوافق الوظيفة الاختيارية المحددة مع وظيفة اختيارية محددة مسبقاً، فسيبقى أكثر الاختيارات فعالة.

تأخير بدء التشغيل ⓘ
لضبط البرنامج المختار للدورة في وقت لاحق، اضغط على الزر لضبط زمن التأخير المرغوب. يضيء الرمز ⓘ على وحدة العرض عند تفعيل هذه الوظيفة. لإلغاء بدء التشغيل اللاحق، اضغط على الزر مرة أخرى إلى أن تظهر القيمة "0" على وحدة العرض.

وظيفة +FreshCare

تساهم هذه الوظيفة الاختيارية في تعزيز قدرة الغسل من خلال توليد البخار لمنع انتشار مصادر الروائح الكريهة المتوجدة داخل الجهاز. وبعد انتهاء مرحلة البخار، تقوم الغسالة بإجراء مرحلة تقليل تخفيف غير تنوير الحلة عدة لفات خففة. وتبدأ الوظيفة الاختيارية +FreshCare بعد انتهاء الدورة وتنstemر لأقصى مدة تبلغ ست ساعات ويمكنك إيقافها في أي وقت بالضغط على أي زر في لوحة التحكم أو من خلال إدارة المفاتيح. وانتظر لمدة 5 دقائق قبل فتح الباب.

درجة الحرارة °C
يشتمل كل برنامج على درجة حرارة محددة مسبقاً. عند الرغبة في تغيير درجة الحرارة، اضغط على الزر "درجة الحرارة" °C. وستنظهر القيمة في وحدة العرض.

عصر Ⓛ

تنظيف فلتر الماء / تصريف الماء المتبقى
 إذا استخدمت برنامج غسل ساخناً، فانتظر حتى يبرد الماء قبل تنظيفه. قم بتنظيف الفلتر بصفة منتظمة، وتجنب حدوث إعاقات لتصريف الماء بعد الغسل بسبب انسداد الفلتر. إذا تعرّض تصريف الماء، توضح وحدة عرض أن فلتر الماء قد يكون مسدوداً.

اخْلُع القاعدة باستخدام مفك: أضغط أحد جانبي القاعدة لأسفل بيديك ثم أدخل المفك في الفتحة الموجودة بين القاعدة واللوحة الأمامية ثم افتح القاعدة. ضع واء مفلاطح وواسع أسفل فلتر الماء لجمع ماء الصرف. أدر الفلتر ببطء عكس اتجاه حركة عقارب الساعة إلى أن يفرغ الماء بالكامل. اترك الماء يتتدفق للخارج دون إزالة الفلتر. عند انتهاء الوعاء،أغلق فلتر الماء من خلال إدارته في اتجاه حركة عقارب الساعة. قم بتفريغ الوعاء. كرر هذه العملية إلى أن يتم تصريف الماء بالكامل. ضع قطعة قماش قطنية أسلف فلتر الماء حتى يمكنها امتصاص كمية صغيرة من الماء المتبقى. ثم اخلع فلتر الماء من خلال إدارته عكس اتجاه حركة عقارب الساعة. قم بتنظيف فلتر الماء: قم بزالة يقابا الماء في الفلتر وقطننته بماء الصنبور. قم بتركيب فلتر الماء وأعد تركيب القاعدة: أعد تركيب فلتر الماء مرة أخرى من خلال إدارته في اتجاه حركة عقارب الساعة. تأكّد من إدارته حتى النهاية، يجب أن يكون مقبض الفلتر في وضع رأسى. لاختبار إحكام فلتر الماء ضد تسرب الماء، يمكنك صب قل واحده من الماء في درج مواد الغسل. أعد تركيب القاعدة.

الملحقات

اتصل بخدمة ما بعد البيع لدينا للتحقق من توافر الكمالات لطرز **المغسالة الذي لديك**.

رفع طقم الرص
 يمكن من خلاله تثبيت مجففتك على السطح العلوي لغسالتك لتوفير المكان وتسهيل وضع وإخراج الغسيل من مجففك في الوضع الأعلى.

النقل والمناولة

لا تقم أبداً برفع الغسالة من خلال إمساكها من منصة العمل.

انزع القابس الكهربائي، وأغلق صنبور الماء. تأكّد من غلق الباب ودرج مواد الغسل بشكل صحيح. افصل خرطوم السحب من صنبور الماء، واطلع خرطوم التصريف من نقطة التصريف. قم بزالة الماء المتبقى بالكامل من الخراطيه، وقم بتثبيتها بحيث لا تتصرّر أثناء النقل. أعد تركيب براغي النقل. اتبع تعليمات فك براغي النقل الواردة في دليل التركيب بترتيب عكسي للخطوات.

يشتمل كل برنامج على عدد لغات للعمر محدد مسبقاً. عند الرغبة في تغيير عدد لغات العصر، اضغط على الزر "عصر" (6). وستظهر القيمة في وحة العرض.
وضع الاستعراض
 هذا الجهاز مزود بوظيفة وضع الاستعراض. وللمزيد من المعلومات، انظر دليل المستخدم/وضع الاستعراض.

ـ قفل المفاتيح ـ

ـ قفل لوحة التحكم، اضغط على الزر "ـ قفل المفاتيح ـ" ـ واحفظ به مضغوطاً لمدة 3 ثوانٍ تقريباً. عندما يظهر بوحدة العرض "ـ قفل المفاتيح مشغل ـ" ، تكون لوحة التحكم مؤمنة القفل (باستثناء الزر "ـ التشغيل/إيقاف ـ" (1)). وبذلك تمنع حدوث تغيير مفاجئ في البرامج، لا سيما عند وجود الأطفال بالقرب من الغسالة. لتحرير قفل لوحة التحكم، اضغط على الزر "ـ قفل المفاتيح ـ" ـ واحفظ به مضغوطاً لمدة 3 ثوانٍ تقريباً.

ـ التبييض ـ

ـ عند الرغبة في تبييض الملابس، ضع الغسيل في الملابس واضبط على البرنامج "ـ شطف وعصر ـ" (2).
 ابدأ تشغيل الجهاز ثم انتظر حتى تكتمل الدورة الأولى لماء الماء (حوالى دقيقة). أوقف الجهاز مؤقتاً بالضغط على الزر "ـ بدء التشغيل/إيقاف المؤقت ـ" (3)، ثم افتح درج مادة الغسل وأضف مادة التبييض (مع مراعاة الجرعات الموصى بها والموضحة على العبوة) في حجرة الغسل.
 الرئيسى المرکب بها الدرج مسبقاً. أعد تشغيل الدورة بالضغط على الزر "ـ بدء التشغيل/إيقاف المؤقت ـ" (4).
 عند الرغبة يمكنك إضافة منعم الملابس في الحجرة المناسبة بدرج مادة الغسل.

ـ إرشادات ونصائح ـ

ـ قم بفرز الغسيل تبعاً للاتي
 نوع القماش/ثيكت المغاسلية (القطن، الألياف مختلطة، الألياف الصناعية، صوف، الملابس التي يتم غسلها يدوياً). اللون (قم بفصل الملابس الملونة والبيضاء، أغسل الملابس الملونة الجديدة بشكل منفصل). المنسوجات الحساسة (قم بغسل قطع الملابس الصغيرة - مثل جوارب النايلون - والملابس ذات الخطافات - مثل حمالات الصدر - في كيس قماشي أو كيس وسادة مغلق بسحاب).

ـ قم بتفريغ جميع الجيوب
 أشياء مثل العملات المعدنية والولايات قد تسبب أضرار لغسالتك بالإضافة للحلة.

ـ التنظيف والصيانة ـ

ـ قم بـإيقاف الغسالة وافصلها عن الكهرباء قبل الشروع في إجراء أعمال
ـ تنظيف أو صيانةـ لا تستخدم السوائل القابلة للاشتعال لتنظيف الغسالة.

ـ **ـ تنظيف الغسالة من الخارجـ**
 استخدم قطعة قماش مبللة تليلاً لتنظيف الأجزاء الخارجية للغسالة. لا تستخدم منظفات الاستخدام العامة أو مسحوقاً خشنّاً أو ما شابه لتنظيف لوحة التحكم - فهو الماء يمكن أن تلحق الضرر بالطلاء.

ـ **ـ فحص خرطوم إمداد الماءـ**
 افحص خرطوم إمداد الماء بصفة منتظمة بحيث عن الهشاشة أو التشققات. وفي حالة وجود ضرر، فاستبدل بخرطوم جديد لدى مركز خدمة ما بعد البيع أو لدى الوكيل المتخصص. حسب نوع الخرطوم: إذا كان خرطوم السحب يحتوي على طلاء شفاف، فافحصه من وقت لآخر لمعرفة ما إذا كانت كثافة اللون تزيد في مواضع معينة. إذا كان الأمر كذلك، فربما يكون هناك تسريب في الخرطوم ويجب تغييره.

ـ **ـ تنظيف الفلتر الشكيـ** في خرطوم إمداد الماء
 أغلق صنبور الماء وقبّل خرطوم السحب من الصنبور. قم بتنظيف الفلتر الشكي الداخلي ثم اربط خرطوم سحب الماء بالصنبور مرة أخرى. والآن، قم بفك خرطوم السحب من ظهر الغسالة. افصل الفلتر الشكي من وصلة الغسالة باستخدام زريبة عامة ثم قم بتنظيف الفلتر. أعد تركيب الفلتر الشكي ثم اربط خرطوم السحب بالغسالة مرة أخرى. افتح صنبور الماء وتتأكد أن جميع الوصلات محكمة تماماً ضد تسريب الماء.

التغلب على الأعطال

قد لا تعمل الغسالة في بعض الأحيان بشكل صحيح لعدة أسباب. وقبل الاتصال بمركز خدمة ما بعد البيع، نوصي بالتحقق ما إذا كان من السهل معالجة العطل أم لا من خلال استخدام القائمة التالية.

الأسباب المحتملة / الحلول:	الاختلافات:
<ul style="list-style-type: none"> لم يتم إدخال القابس في المقبس الكهربائي، أو غير متصل بالقدر الكافي. حدث عطل كهربائي. باب غير مغلق بالكامل. 	الغسالة لا تقوم بالتشغيل.
<ul style="list-style-type: none"> لم يتم الضغط على زر "التشغيل/الإيقاف". لم يتم الضغط على زر "بدء التشغيل/الإيقاف المؤقت". صنبور الماء غير مفتوح. تم ضبط "تأجيل بدء التشغيل". 	دورة الغسل لا تبدأ.
<ul style="list-style-type: none"> خرطوم سحب الماء غير متصل بالصنبور. الخرطوم مثني. صنبور الماء غير مفتوح. تم إيقاف مصدر الإمداد بالماء. لا يوجد ضغط كافي. 	الغسالة لا تقوم بملء الماء (يظهر البيان "h2o" على وحدة العرض). تصدر "صافرة" كل خمس ثوان.
<ul style="list-style-type: none"> لم يتم الضغط على زر "بدء التشغيل/الإيقاف المؤقت". لم يتم تركيب خرطوم التصريف على بعد يتراوح من 65 سم إلى 100 سم من الأرض. طرف خرطوم التصريف مغمور بالماء. وصلة التصريف المثبتة بالحانط ليس بها فتحة تهوية. إذا اشتركت المشكلة في الظهور بعد القيام بهذه الفحوصات، أغلق صنبور الماء، أوقف الغسالة واتصل بمركز خدمة ما بعد البيع. إذا كنت تسكن في أعلى طابق بالبني، فقد يكون للسحب تأثيراً يجعل الغسالة تقوم بتنعينة وتصريف الماء باستمرار. ويتوفر بالأسواق الصمامات الخاصة المانعة للسحب لمنع وقوع مثل هذا النوع من الأعطال. 	الغسالة تقوم بتنعينة وتصريف الماء باستمرار.
<ul style="list-style-type: none"> البرنامج لا يشتمل على وظيفة التصريف: مع برامج محددة يجب التفعيل يدوياً. خرطوم التصريف مثني. MASORAH التصريف مسدودة. 	الغسالة لا تقوم بتصريف الماء أو لا تقوم بالعصير.
<ul style="list-style-type: none"> أثناء التركيب، لم يتم تحرير قفل الحلة بشكل صحيح. الغسالة ليست مسrovée. الغسالة محصورة بين الأثاث والحانط. 	الغسالة تهتز بشدة أثناء دورة العصر.
<ul style="list-style-type: none"> لم يتم إحكام ربط خرطوم سحب الماء بشكل صحيح. درج مادة الغسل مسدود. لم يتم ربط خرطوم التصريف بشكل صحيح. 	يتسرّب الماء من الغسالة.
<ul style="list-style-type: none"> أوقف الجهاز، افصل القابس عن المقبس، وانتظر لمدة دقيقة قبل إعادة تشغيله. إذا استمر العطل، اتصل بمركز خدمة ما بعد البيع. 	الجهاز مؤمن القفل وتومض وحدة العرض، مشيرة إلى كود الخطأ (على سبيل المثال F-01-F...).
<ul style="list-style-type: none"> مادة الغسل غير متناسبة مع الغسالة (يجب أن تحمل التعبيرات " المناسب للغسالات" ، " مناسب للغسل اليدوي أو الغسالات الآوتوماتيك" ، أو ما شابه). الكمية زائدة عن الحد. 	ت تكون الرغاوي بكميات كبيرة للغاية.
<ul style="list-style-type: none"> تم تأمين قفل الباب في حالة انقطاع الكهرباء. يستمر البرنامج أوتوماتيكياً بمجرد عودة التيار الكهربائي. الغسالة في وضع الإيقاف. يستمر البرنامج أوتوماتيكياً بعد زوال سبب التوقف. 	الباب مؤمن القفل، مع أو بدون بيان العطل، والبرنامج لا يقوم بالتشغيل.



يمكنك تنزيل تعليمات الأمان ودليل المستخدم وكتيب المنتج وبيانات الطاقة من خلال:

زيارة موقعنا - docs.whirlpool.eu

استخدام كود الاستجابة السريع QR

وكل بديل، اتصل بمركز خدمة ما بعد البيع (انظر رقم الهاتف الوارد في كتيب الضمان). يرجى عند الاتصال بخدمة ما بعد البيع ذكر الأكواد المذكورة على لوحة تمييز المنتج.



سلوفاكيا	بلد الإنتاج
FWF71052W GCC	نموذج الوصف
V 220/240	الفولطية المقدرة (V)
Hz 50	التردد المقدر (Hz)
W 1850	الطاقة المقدرة (W)
kg 66	الوزن الصافي (kg)
من 1 إلى 7 كجم	السعة
kWh/year 206	الطاقة السنوية استهلاك (kWh/year)
liters/year 8900	الماء السنوي استهلاك (liters/year)
العرض 59.5 سم الارتفاع 85 سم العمق 57.5 سم	الأبعاد
قم بتصريف خرطوم تصريف الماء، من دون ثنيه، بأسلوب تصريف أو بتصريف جداري على ارتفاع يتراوح بين 65 و حتى 100 سم عن الأرض؛ بدلاً من ذلك، ضع خرطوم التصريف على حافة حوض الغسيل أو حوض الاستحمام، من خلال ربط الدليل  (الذي يمكن شراؤه من مركز المساعدة الفنية) بالصنبور (أنظر الشكل). على الطرف الحر من الخرطوم لا يكون تحت الماء. وصل خرطوم تصريف الماء ! نحن لا ننصح باستخدام إطارات الخرطوم؛ إذا كان ذلك ضروريًا جداً، فعلى الإطارات أن تكون بنفس قطر الخرطوم الأصلي على الأقل يتدنى طوله 150 سم.	وصل خرطوم تصريف الماء
قبل توصيل الجهاز بمصدر الطاقة، تأكد من أن: • المقبس موزرض ويدعى لكل الفوانين الواجب تطبيقها؛ • المقبس قادر على تحمل عبء الطاقة القصوى للجهاز، كما هو مبين في شريحة البيانات التقنية المثبتة على الماكينة؛ • الجهد الكهربائي لمصدر التيار في نطاق يتراوح بين القيم المشار إليها في لوحة البيانات الموجودة على الماكينة. • المقبس متوافق مع قابس الماكينة. إذا لم يكن الأمر كذلك، قم بتبدل المقبس أو القابس.	التوصيات الكهربائية
تم تصميم هذا الجهاز للاستخدام المنزلي فقط. • هذا الجهاز غير معد للاستخدام من قبل الأشخاص (من بينهم الأولاد) ذوي الإعاقات الجسمية، النفسية أو العقلية، أو من من لديهم تجربة قليلة ومعرفة محدودة، إلا إذا تم إرشادهم أو تدريتهم فيما يتعلق باستخدام الجهاز، من قبل شخص مسؤول عن أمانهم. يجب مراعاة الأولاد للتأكد من أنهم لا يعيثون بالجهاز. • لا تلامس الماكينة وأنت حافي القدمين أو بيدين ورجليين مبالتين أو رطين. • لا تمس سحب كل تزويد الطاقة عند فصل الجهاز عن مقبس شبكة الطاقة الكهربائية. امسك القابس واسحبه. • لا تفتح درج وعاء مواد التنظيف بينما تكون الماكينة قيد التشغيل. • لا تلامس ماء الصرف، حيث يمكن أن يكون بدرجة حرارة عالية جداً. • لا تدفع بباب الفتحة بشدة: يمكن لذلك أن يتلف ميكانيكية قفل الأمان المصمم لمنع فتحه عن غير قصد. • إذا تعطل الجهاز، لا تحاول بأي حال من الأحوال، الوصول إلى الأجهزة الداخلية في محاولة لتصليحها بنفسك. • أبق الأطفال بعيدين عن الجهاز دائمًا أثناء عمله. • يمكن للباب أن يصبح ساخناً بعض الشيء خلال دورة الغسيل. • إذا كانت هناك حاجة لنقل الجهاز، نفذ العمل بمجموعة من شخصين أو ثلاثة أشخاص وتعاملوا معه بمنتهى الحذر. لا تحاول أبداً القيام بذلك لوحده، لأن الجهاز ثقيل جداً. • قبل إدخال الغسيل إلى ماكينة الغسيل، تأكد من أن البرميل فارغ. • يجب عدم تشغيل هذه الماكينة في بيئة غير مكافحة الهواء.	الوقاية العامة
1. أخرج ماكينة الغسيل من رزمتها. 2. تأكد من أنه لم يلحق ضرر بـماكينة الغسيل خلال الشحن. إذا لحق بها ضرر، اتصل بالموزّع ولا تنفذ أية عملية تركيب إضافية. 3. فك البراغي الـ 4 الواقعية (المستخدمة خلال الشحن) واطيل الماكينة مع حافظ المسافة الملام الموجود في الجهة الخلفية من الجهاز (أنظر الشكل). 4.أغلق الفتحات باستخدام الأغطية البلاستيكية المزودة. 5. أبق كل الأجزاء في مكان آمن: سوف تحتاجها مرة أخرى في حال تم نقل ماكينة الغسيل إلى موقع آخر. ! يجب عدم استخدام مواد التعبئة كألعاب للأولاد.	إفراج المحتويات وتحديد المستوى

THANK YOU FOR BUYING A WHIRLPOOL PRODUCT.

In order to receive a more complete assistance, please register your product on www.whirlpool.eu/register



Before using the appliance carefully read the Safety Instruction.

Before using the machine, it is imperative that the transport bolts are removed. For more detailed instructions on how to remove them, see the Installation Guide.

CONTROL PANEL


- 1 "ON/OFF" button
- 2 Programme selector
- 3 "Start/Pause" button
- 4 "Spin" button
- 5 "Start delay" button
- 6 "FreshCare+" / "Key lock" button
- 7 "Temperature" button

DISPLAY INDICATORS

Door locked

FreshCare+ activated

Start delay activated



7. 6.

3. 4. 5.

Key lock activated

Washing phase

Indicates washing phase of the cycle

Failure: Call Service

Refer to Troubleshooting section

Failure: Water filter clogged

Water cannot be drained; water filter might be blocked

Failure: No water

No or not sufficient inlet water.

In the event of any failure, refer to the "TROUBLESHOOTING" section

PROGRAMME CHART

Max load 7 Kg Power consumption in off-mode 0.5 W / in left-on mode 8.0 W					Detergents and additives			Recommended detergent		Residual dampness %*	Energy consumption kWh	Total water lit
Programme	Temperatures		Max. spin speed (rpm)	Max load (kg)	Duration (Minutes)	Prewash	Main wash	Softener	Powder	Liquid		
	Default	Range										
Mixed	40°C	* - 40°C	1000	3.5	**	—			—		—	—
White (1)	60°C	* - 90°C	1000	7.0	**						—	—
Cotton	40°C	* - 60°C	1000	7.0	220	—					62	0.98
eCotton (2)	60°C	* - 60°C	1000	7.0	275	—					62	0.89
Sport	40°C	* - 40°C	600	3.5	**	—			—		—	—
Duvet	30°C	* - 30°C	1000	2.0	**	—			—		—	—
Jeans	40°C	* - 40°C	800	3.5	**	—			—		—	—
Spin & Drain	—	—	1000	7.0	**	—	—	—	—	—	—	—
Rinse & Spin	—	—	1000	7.0	**	—	—		—	—	—	—
Rapid 30'	30°C	* - 30°C	800	3.0	**	—			—		—	—
Colours 15°	15°C	15°C	1000	3.5	**	—			—		—	—
Wool	40°C	* - 40°C	800	1.5	**	—			—		—	—
Delicates	30°C	* - 30°C	—	1.0	**	—			—		—	—
Synthetics	40°C	* - 60°C	1000	4.0	195	—					33	0.75
Dosing required Dosing optional												72

Dosing required Dosing optional

Cotton - Test wash cycles in compliance with regulations 1061/2010

These are the reference programs for the energy label. Set this wash cycle with a temperature of 60°C. They are the most efficient programmes in terms of energy and water consumption for washing normally soiled cotton laundry. The actual water temperature may differ from the declared one.

For all Test Institutes

Long wash cycle for cottons: set wash cycle **Cotton** with a temperature of 40°C. Synthetic program along: set wash cycle **Synthetics** with a temperature of 40°C.

1) Test wash cycle according to UAE.S 5010-2 : 2019 regulations:

Set wash program at a temperature of 60°C for the Standard Cotton 60°C.

2) Test programmes according to OS 1651/2022: set the wash cycle with a temperature of 60°C for Cotton Standard 60°C and the wash cycle with temperature of 40°C for Cotton Standard 40°C.

2) Test programmes according to KWS 1899:2023: set the wash cycle with a temperature of 60°C for Cotton Standard 60°C and the wash cycle with temperature of 40°C for Cotton Standard 40°C.

This data may differ in your home due to changing conditions in inlet water temperature, water pressure etc. Approximate programme duration values refer to the default setting of the programmes, without options.


* After programme end and spinning with maximum selectable spin speed, in default programme setting.

** The duration of the programme is shown on the display.

The washer adapts water, energy and programme duration to your wash load.

PRODUCT DESCRIPTION

1. Worktop
2. Detergent dispenser
3. Control panel
4. Door handle
5. Door
6. Water filter - behind plinth
7. Plinth (removable)
8. Adjustable feet (4)



DETERGENT DISPENSER

Main wash compartment

Detergent for the main wash, stain remover or water softener. For a liquid detergent it is recommended to use removable plastic partition **A** (supplied) for a proper dosage. If powder detergent is used, place the partition into slot **B**.

Prewash compartment

Detergent for the prewash.


Softener compartment

Fabric softener. Liquid starch.

Pour in softener or starch solution only up to the "max" mark.

Release button

Press to remove tray for cleaning.



PROGRAMMES

For choosing the appropriate programme for your kind of laundry, always respect the instructions on the care labels of the laundry. The value given in the tub symbol is the maximum temperature possible for washing the garment.



Mixed

For washing lightly to normally soiled resilient garments in cotton, linen, synthetic fibres and mixed fibres.

White

For washing normally to heavily soiled towels, underwear, table and bed linen, etc in resilient cotton and linen. Only when the temperature is selected at 90°C the cycle is provided with a prewash phase before main washing phase. In this case it is recommended to add detergent both, in the prewash and main wash section.

Cotton

Normally to heavily soiled and robust cottons.

Cotton

For washing normally soiled cotton garments. At 60°C, this is the standard cotton programme and the most efficient in terms of water and energy consumption.

Sport

For washing lightly soiled sports clothing (tracksuits, shorts, etc.). For best results, we recommend not exceeding the maximum load indicated in the, "PROGRAMME CHART". We recommend using liquid detergent, and adding the amount suitable for half-load.

Duvet

Designed for washing eiderdown padded items such as double or single duvets, cushions and anoraks. It is recommended to load such padded items in the drum with the edges folded inwards and not to exceed ¾ of the drum's volume. For optimal washing, we recommend using a liquid detergent.

Jeans

Turn garments inside-out before washing and use a liquid detergent.

Spin & Drain

Spins the load then empties the water. For resilient garments. If you exclude the spin cycle, the machine will drain only

Rinse & Spin

Rinses and then spins. For resilient garments.

Rapid 30'

For washing lightly soiled garments quickly. This cycle lasts only 30 minutes, saving time and energy.

Colours 15°

This cycle helps protect colours by washing in cold water (15°C) and uses less energy to heat the water while still offering satisfactory wash results. Suitable for lightly soiled, unstained garments. This cycle offers wash results comparable to 40°C mixed at just 15°C

Wool

All wool garments can be washed using programme "Wool" even those carrying the "hand-wash only" label. For best results, use special detergents and **do not exceed max kg declaration of laundry**.

Delicates

For washing particularly delicate garments. Preferably turn garments inside out before washing.

Synthetics

For washing soiled garments made from synthetic fibres (such as polyester, polyacrylic, viscose, etc.) or cotton/synthetic blends.

FIRST TIME USE

To remove any manufacturing debris select the "Cotton" programme at a temperature of 60°C. Pour a small quantity of detergent powder into the main wash compartment of the detergent dispenser (maximum 1/3 of the quantity the detergent manufacturer recommends for lightly soiled laundry). Start the programme **without adding any laundry**.

DAILY USE

Prepare your laundry according to the recommendations in the "HINTS AND TIPS" section. Load the laundry, close the door, open the water tap and press the "ON/OFF" button to switch the wasching machine on, the "Start/Pause" button flashes. Turn the programme selector to the desired programme and select any option if needed. The temperature and spin speed can be changed by pressing the "Temperature" button or the "Spin" button. Pull out the detergent dispenser and add the detergent (and additives/softener) now. Observe the dosing recommendations on the detergent pack. Then close the detergent dispenser.

STARTING CYCLE

Close the detergent dispenser and press the "Start/Pause" button. The machine will lock the door (symbol on) and the drum will start to rotate; the door will be unlocked (symbol off) and then locked again (symbol on) as preparation phase of each washing cycle. The "Clicking" noise is part of the door locking mechanism. Water will enter the drum and start the washing phase once the door is locked.

PAUSE A RUNNING PROGRAMME

To pause the wash cycle, press the "Start/Pause" ; the indicator light will go off and the remaining time on display flash. To start the wash cycle from the point at which it was interrupted press the button again.

OPEN THE DOOR, IF REQUIRED

After starting a programme, the "Door locked" indicator lights up to show that the door can not be opened. As long as a wash programme is running, the door remains locked. To open the door while a programme is in progress, press the "Start/Pause" to pause the programme. Provided the water level and/or temperature is/are not too high, the "Door locked" indicator light goes off and you can open the door. For example to add or remove laundry. Press the "Start/Pause" button again to continue the programme.

PROGRAMME END

The "Door locked" indicator light goes off and the display shows "End". To switch off the washing machine after programme ends press the "ON/OFF" button, the lights goes off. If you do not press "ON/OFF" button, the washing machine will switch off automatically after about a half of an hour. Close the water tap, open the door and unload the washing machine. Leave the door ajar to allow the drum to dry.

OPTIONS

! If the selected option is incompatible with the programme set, the incompatibility will be signalled by a buzzer (3 beeps) and the corresponding indicator light will flash.

! If the selected option is incompatible with another previously set option, only the most recent selection will remain active.

Start delay

To set the selected programme to start at a later time, press the button to set the desired delay time. Symbol lights on the display when this function is enabled. To cancel the delayed start, press the button again until the value, "0" is shown on the display.

FreshCare+

This option enhances washing performance by generating steam to inhibit the proliferation of the main bad odour sources inside the machine. After steam phase, the washing machine will perform gentle tumbling through slow rotations of the drum. FreshCare+ option starts after the cycle ends for a maximum duration of 6h and you can interrupt it at any time by pressing any button on control panel or turning the knob. Wait around 5 minutes before door can be opened.

Temperature

Every programme has a predefined temperature. If you want to change the temperature, press the "Temperature" button. The value appears on the display.

Spin 

Every programme has a predefined spin speed. If you want to change the spin speed, press the "Spin"  button. The value appears on the display.

Demo mode

This appliance is equipped with Demo mode function. For more information see the USER MANUAL/ Demo Mode.

KEY LOCK 

To lock the control panel, press and hold the "Key lock"  button for approximately 3 seconds. When the display visualises a key symbol , the control panel is locked (with the exception of the "ON/OFF"  button). This prevents unintentional changes to programmes, especially with children near the machine. To unlock the control panel, press and hold the "Key lock"  button for approximately 3 seconds again.

BLEACHING

If you wish to bleach the laundry, load the washing machine and set the "Rinse & Spin" programme .

Start the machine and wait for it to complete the first water filling cycle (roughly 2 minutes). Put the machine in pause mode by pressing the "Start/Pause"  button, open the detergent drawer and pour the bleach (observe the recommended doses indicated on the package) into the main wash compartment where the partition was previously mounted. Restart the cycle by pressing the "Start/Pause"  button.

If desired, it is possible to add fabric softener into the appropriate compartment of the detergent drawer.

HINTS AND TIPS**Sort your laundry according to**

Type of fabric/care label (cotton, mixed fibres, synthetics, wool, handwash items). Colour (separate coloured and white items, wash new coloured items separately). Delicates (wash small items – like nylon stockings – and items with hooks – like bras – in a cloth bag or pillow case with zip).

Empty all pockets

Objects like coins or lighters can damage your laundry as well as the drum.

CLEANING & MAINTENANCE

For any cleaning and maintenance, switch off and unplug the washing machine. Do not use flammable fluids to clean the washing machine.

Cleaning the outside of the washing machine

Use a soft damp cloth to clean the outer parts of the washing machine. Do not use glass or general purpose cleaners, scouring powder or similar to clean the control panel – these substances might damage the printing.

Checking the water supply hose

Check the inlet hose regularly for brittleness and cracks. If damaged, replace it by a new hose available through our After-Sales Service or your specialist dealer. Depending on the hose type: If the inlet hose has a transparent coating, periodically check if the colour intensifies locally. If yes, the hose may have a leak and should be replaced

Cleaning the mesh filters in the water supply hose

Close the tap and loosen the inlet hose on the tap. Clean the internal mesh filter and screw the water inlet hose back onto the tap. Now unscrew the inlet hose on the rear of the washing machine. Pull off the mesh filter from the washing machine connection with universal pliers and clean it. Refit the mesh filter and screw the inlet hose on again. Turn on the tap and ensure that the connections are completely water-tight.

Cleaning the water filter / draining residual water

If you used a hot wash programme, wait until the water has cooled down before draining any water. Clean the water filter regularly, to avoid that the water cannot drain after the wash due to obstruction of the filter. If the water cannot drain, the display indicates that the water filter may be clogged.

Remove the plinth by using the screwdriver: push downwards one side of the plinth with your hand, then push the screwdriver into the gap between plinth and front panel and pry open the plinth. Place a broad, flat container beneath the water filter, to collect the drain water. Slowly turn the filter counterclockwise until water flows out. Let the water flow out, without removing the filter. When the container is full, close the water filter by turning it in clockwise. Empty the container. Repeat this procedure until all the water has drained. Lay a cotton cloth beneath the water filter, which can absorb a small amount of rest water. Then remove

the water filter by turning it out anti clockwise. Clean the water filter: remove residues in the filter and clean it under running water. Insert the water filter and reinstall the plinth: Reinsert the water filter again by turning it in clockwise direction. Make sure to turn it in as far as it goes; the filter handle must be in vertical position. To test water tightness of the water filter, you can pour about 1 liter of water into the detergent dispenser. Then reinstall the plinth.

ACCESSORIES

Contact our After-Sales Service to check if the following accessories are available for your washing machine model.

Stacking kit shelf

By which your dryer can be fixed on top of your washing machine to save space and to facilitate loading and unloading your dryer in the higher position.

TRANSPORT AND HANDLING

Never lift the washing machine by holding it at the worktop.

Pull out the mains plug, and close the water tap. Make sure that door and detergent dispenser are properly closed. Disconnect the inlet hose from the water tap, and remove the drain hose from your draining point. Remove all rest water from the hoses, and fix them so that they cannot get damaged during transport. Refit the transport bolts. Follow the instructions for removing the transport bolts in the INSTALATION GUIDE in reverse order.

TROUBLESHOOTING


The washing machine may sometimes not work properly for certain reasons. Before calling the After-sales service, it is recommended to check to see if the problem can be easily resolved using the following list.

Anomalies:	Possible causes / Solution:
The washing machine does not turn on.	<ul style="list-style-type: none"> The plug is not inserted into the electrical outlet, or not enough to make contact. There has been a power failure. The door is not fully closed.
The wash cycle does not start.	<ul style="list-style-type: none"> The "ON/OFF"  button has not been pressed. The "Start/Pause"  button has not been pressed. The water tap is not open. A "Start delay"  has been set.
The washing machine does not fill with water (the message "h2o" is shown on the display). "Beep" sound every 5 seconds.	<ul style="list-style-type: none"> The water intake hose is not connected to the tap. The hose is bent. The water tap is not open. The mains water supply has been shut off. There is not enough pressure.
The washing machine loads and drains water continuously.	<ul style="list-style-type: none"> The "Start/Pause"  button has not been pressed. The drain hose has not been installed at 65 to 100 cm from the ground. The end of the drain hose is immersed in water. The drain connector on the wall does not have an air vent. If the problem persists after having performed these checks, close the water tap, shut off the washing machine, and call the After-sales service. If the dwelling is located on one of the uppermost floors of a building, a siphon effect can sometimes occur, thus causing the washing machine to load and drain water continuously. Special anti-siphon valves are available on the market to prevent these types of problems.
The washing machine does not drain or does not spin.	<ul style="list-style-type: none"> The programme does not include the draining function: with certain programmes it must be activated manually. The drain hose is bent. The drain line is obstructed.
The washing machine vibrates excessively during the spin cycle.	<ul style="list-style-type: none"> At the time of installation, the drum was not properly unblocked. The washing machine is not level. The washing machine is squeezed between furniture and the wall.
The washing machine leaks water.	<ul style="list-style-type: none"> The water intake hose has not been tightened properly. The detergent dispenser is clogged. The drain hose has not been properly fastened.
The machine is locked and the display flashes, indicating an error code (e.g. F-01, F-..).	<ul style="list-style-type: none"> Shut off the machine, disconnect the plug from the outlet, and wait about 1 minute before turning it back on. If the problem persists, call the After-sales service.
Too much foam is formed.	<ul style="list-style-type: none"> The detergent is not compatible with the washing machine (it must bear the wording "for washing machines", "for hand washing and washing machines", or something similar). The dosage was excessive.
Door is locked, with or without failure indication, and the programme does not run.	<ul style="list-style-type: none"> Door is locked in case of power breakdown. Programme will continue automatically as soon as the mains is available again. Washing machine is in a standstill. Programme will continue automatically after the origin of the standstill does not persist anymore.



You can download the Safety Instructions, User Manual, Product Fiche and Energy data by:

- Visiting our website - docs.whirlpool.eu
- Using QR Code
- Alternatively, **contact our After-sales Service** (See phone number in the warranty booklet). When contacting our After-sales Service, please state the codes provided on your product's identification plate.



Manufacturer's name	BEKO EUROPE MANAGEMENT S.R.L., VIA VARESINA, 204 20156 MILANO ITALY
Description model	FWF71052W GCC
Country of production	Slovakia
Rated Voltage (V)	220/240 V
Rated Frequency (Hz)	50 Hz
Rated Power (W)	1850 W
Net Weight (kg)	66 kg
Rated Capacity (kg)	7 kg
Annual Energy Consumption (kWh/year)	206 kWh/year
Annual Water Consumption (liters/year)	8900 liters/year
Dimensions	width 59.5 cm height 85 cm depth 57,5 cm
Connecting the drain hose	Connect the drain hose, without bending it, to a drain duct or a wall drain situated between 65 and 100 cm from the floor. Alternatively, place the drain hose over the edge of a washbasin or bathtub, by fastening the guide (which can be purchased at the technical assistance centre) to the tap. The free end of the hose should not be underwater. ! We advise against the use of hose extensions; if it is absolutely necessary, the extension must have the same diameter as the original hose and must not exceed 150 cm in length.
Electrical connections	Before plugging the appliance into the mains socket, make sure that: <ul style="list-style-type: none">• the socket is earthed and in compliance with the applicable law;• the socket is able to sustain the appliance's maximum power load indicated on the Technical Data Plate fixed on the machine;• the supply voltage is included within the values indicated on the Technical Data Plate fixed on the machine.• the socket is compatible with the washing machine's plug. If this is not the case, replace the socket or the plug.
General safety	<ul style="list-style-type: none">• This appliance was designed for domestic use only.• This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.• Do not touch the machine when barefoot or with wet or damp hands or feet.• Do not pull on the power supply cable when unplugging the appliance from the electricity socket. Hold the plug and pull.• Do not open the detergent dispenser drawer while the machine is in operation.• Do not touch the drained water as it may reach extremely high temperatures.• Never force the porthole door. This could damage the safety lock mechanism designed to prevent accidental opening.• If the appliance breaks down, do not under any circumstances access the internal mechanisms in an attempt to repair it yourself.• Always keep children well away from the appliance while it is operating.• The door can become quite hot during the wash cycle.• If the appliance has to be moved, work in a group of two or three people and handle it with the utmost care. Never try to do this alone, because the appliance is very heavy.• Before loading laundry into the washing machine, make sure the drum is empty.• This machine must not be operated in a non air-conditioned environment.
Unpacking and levelling	<ol style="list-style-type: none">1. Remove the washing machine from its packaging.2. Make sure that the washing machine has not been damaged during the transportation process. If it has been damaged, contact the retailer and do not proceed any further with the installation process.3. Remove the 4 protective screws (used during transportation) and the rubber washer with the corresponding spacer, located on the rear part of the appliance.4. Close off the holes using the plastic plugs provided.5. Keep all the parts in a safe place: you will need them again if the washing machine needs to be moved to another location. ! Packaging materials should not be used as toys for children.



400020014670